



ZEBRONICS
ALWAYS AHEAD

Wireless Neckband Earphone
ZEB **YOGA**10



User Manual

www.zebronics.com

Thank You for purchasing **ZEB-YOGA 10** Wireless neckband earphone. Please read this user manual carefully before operation & save it for future reference.

Note:

- Please full charge the product with a power adapter output rated DC 5V before first time usage.
- Do not self-disassemble the product or it will result in the failure of warranty.
- Make sure not to use this product at any high-temperature or high humidity environment.

***Caution:** Listening at high volume can cause hearing impairment. Please limit your usage time at high volume.*

Features

Wireless BT earphone with Neckband

Volume/Media Control

Call Function

Voice Assistant support

Built-In Rechargeable Battery

Flexible Neckband

Type-C Charging

Environmental Noise Cancellation (ENC)

Gaming Mode (Low Latency)

Dual Pairing

Specifications

BT Version	: 5.2
Supported BT Profile	: HSP / SPP / A2DP / AVRCP
Drive size	: 14.2mm
Speaker impedance	: 32Ω
Playback time	: 70h*
Charging time	: 1.5 h
Talk time	: 42-44h
Standby time	: 400h
Net. weight	: 40g

Package contents

Neckband	: 1 U
Eartips	: 4 U
Charging cable	: 1 U
QR Code Guide	: 1 U

** at 50% volume*

Usage Instruction:


Bluetooth Pairing Instructions:

STEP 1 - Press and hold the MFB to power ON the earphones and to take them into pairing mode with Red & Blue LED blinking alternatively.

STEP 2 - Switch ON the Bluetooth in your mobile phone & search for the BT name **"ZEB-YOGA 10"**

STEP 3 - Once the BT name is visible in your mobile phone, tap to connect it.

Product Representation



Button Usage:

MFB Single Press : Play/Pause the music

MFB Double Press :

Switch mode b/w Gaming / Music mode

MFB Press & Hold : Wakeup Voice assistant

MFB Short Press : To answer call/endup the call

MFB Long Press : Call Reject

Short Press +/- : Volume Up and Down

Long Press +/- : Next / Previous track

Activating Smart Phone's Voice Assistant:

When the neckband is connected to a mobile phone, Press and hold the MFB for 2 seconds to activate voice assistant.

***Note:** Smart phone should have an active internet connection to use the voice assistant function.*

Call Function:

- Short press the MFB to attend or end the call.
- Press and Hold the MFB for 2 seconds to reject the incoming call.

Charging Instruction:

Connect the Type-C charging cable to the

charging port of the earphones & connect the other end to the DC 5V adapter.

LED Indication:

Charging indication : Red LED glows

Full charge indication : LED turns Off

BT Discover mode : Red & Blue LED blinks rapidly till it gets paired.

ISO 9001:2015 Certified Company

www.zebronics.com

