



ZEBRONICS

Wireless Neckband Earphone

YOGA 111

User Manual

www.zebronics.com

Thank You for purchasing **ZEB-YOGA 111** Wireless neckband earphone. Please read this user manual carefully before operation & save it for future reference.

Note:

- Please full charge the product with a power adapter output rated DC 5V before first time usage.
- Do not self-disassemble the product or it will result in the failure of warranty.
- Make sure not to use this product at any high-temperature or high humidity environment.

***Caution:** Listening at high volume can cause hearing impairment. Please limit your usage time at high volume.*

Features

Wireless BT Earphone with Neckband

Volume/Media Control

Call Function

MagSnap

Voice Assistant support

Built-In Rechargeable Battery

Flexible Neckband

Type-C Charging

Environmental Noise Cancellation (ENC)

Gaming Mode (Low Latency)

Dual Pairing

Specifications

BT Version	: 5.3
Supported BT Profile	: HFP / AVRCP / A2DP
Drive Size	: 10mm
Speaker Impedance	: 32Ω
Playback Time	: 50h*
Charging Time	: 2.5h
Talk Time	: 32h*
Standby Time	: 150h
Net. Weight	: 32.7g

Package contents

Neckband	: 1 U
Eartips	: 4 U
Charging Cable	: 1 U
QR Code Guide	: 1 U

** at 50% Volume*

Usage Instruction:


Bluetooth Pairing Instructions:

STEP 1 - Press and hold the MFB to power ON the earphones and to take them into pairing mode with Red & Blue LED blinking alternatively.

STEP 2 - Switch ON the BT in your mobile phone & search for the BT name **"ZEB-YOGA 111"**

STEP 3 - Once the BT name is visible in your mobile phone, tap to connect it.

Product Representation



Button Usage:

MFB Double Press : Connects to Recent Call

MFB 3 Press : Switch Mode between Gaming / Music

MFB Press & Hold : Power On/Off

MFB Long Press : Wakes Voice Assistant

Short Press +/- : Volume Up and Down

Long Press +/- : Next / Previous Track

***Note:** Smart phone should have an active internet connection to use the voice assistant function.*

Call Function:

- Short press the MFB to attend or end the incoming call.
- Press and Hold the MFB for 2 seconds to reject the incoming call.

Play/Pause:

With a magnetic switch, these earbuds pause when snapped together and play your music when pulled apart.

Charging Instruction:

Connect the Type-C charging cable to the charging port of the earphones & connect the other end to the DC 5V adapter.

LED Indication :

Charging Indication : Red LED glows

Full Charge Indication : LED turns Off

BT Discover Mode : Red & Blue LED
blinks rapidly till it gets paired.

ISO 9001:2015 Certified Company

www.zebronics.com

