ZEBRONICS
ALWAYS AHEAD

Wireless Neckband Earphone

ZEB YOGA6

User Manual

Thank You for purchasing **ZEB-YOGA 6** Wireless neckband earphone. Please read this user manual carefully before operation & save it for future reference.

Note:
• Please full charge the product with a power adapter output rated DC 5V before first time usage.
• Do not self-disassemble the product or it will result in the failure of warranty.
• Make sure not to use this product at any high-temperature or high humidity environment.

Caution: Listening at high volume can cause hearing impairment. Please limit your usage time at high volume.

Features
Wireless BT Earphone with Neckband
Volume / Media control
Magnetic earpiece
Environmental Noise Cancellation (ENC)
Call function
Dual pairing
Voice Assistant support
Type C Charging
160h* Playback
1000mAh built-in rechargeable battery
Gaming mode (Low latency)

Specifications

BT Version	: 5.2
Supported BT Profile	: HSP / SPP / A2DP / AVRCP
Drive size	: 10mm
Speaker impedance	: 16Ω
Playback time	: 160h*
Charging time	: 2.5 h
Talk time	: 100h*
Standby time	: 1000h
Net. weight	: 54g

Package contents

Neckband	: 1 U
Eartips	: 4 U
Charging cable	: 1 U
QR Code guide	: 1 U

at 50% volume

Usage Instruction:

Bluetooth Pairing Instructions:

STEP 1 - Press and hold the MFB to power ON the earphones and to take them into pairing mode with Red & Blue LED blinking alternatively.

STEP 2 - Switch ON the Bluetooth in your mobile phone & search for the BT name **"ZEB-YOGA 6"**

STEP 3 - Once the BT name is visible in your mobile phone, tap to connect it.

Product Representation

Vol+ / Next　　　　**MFB**　　　**Vol- / Previous**

Button Usage:

MFB Single Press : Play/Pause the music

MFB Double Press : Gaming mode

MFB Press & Hold : Wake up Voice assistant

Short Press +/- : Volume Up and Down

Long Press +/- : Next / Previous

Activating Smart Phone's Voice Assistant:

When the neckband is connected to a mobile phone, Press and hold the MFB for 3 seconds to activate voice assistant.

Note: Smart phone should have an active internet connection to use the voice assistant function.

Call Function:

• Short press the MFB to attend or end the incoming call.

• Press and Hold the MFB for 2 seconds to reject the incoming call.

Charging Instruction:

Connect the Type-C charging cable to the charging port of the earphones & connect the other end to the DC 5V adapter.

LED Indication:

Charging indication : Red LED glows

Full charge indication : LED turns Off

BT Discover mode : Red & Blue LED blinks rapidly till it gets paired