



ZEBRONICS
ALWAYS AHEAD

2.1 SPEAKER
ZEB **UDAAN** PRO



User Manual

www.zebronics.com

Thank you for purchasing the **ZEB-UDAAN PRO 2.1** Speaker. Please read the user manual carefully before usage & save it for future reference.

Note:

- *Avoid the usage of this speaker at the high temperature and high humidity environment.*
- *Avoid the self-disassembly of the product or it results in voiding the product's warranty.*
- *Turn off the speaker when the speaker is not in use.*
- *To know more about Terms and conditions for warranty policy, please visit*

<https://zebronics.com/pages/warranty-policy>

Features

2.1 Channel Speaker

Wireless BT/USB/AUX/FM

LED Display

Multi Color LED

Remote Control

Volume, Bass & Treble Adjustment

Wall Mountable

Specifications

Output power (RMS)

Subwoofer : 30W

Satellite : 15W x 2

Total : 60W

Driver size

Subwoofer : 10.16 cm


Satellite : 7.62 cm x 2

Impedance	
Subwoofer	: 4Ω
Satellite	: 4Ω
Frequency response	: 40Hz - 20kHz
S/N Ratio	: ≥70dB
Separation	: ≥75dB
File format	
support (USB)	: MP3
Line input	: 2ch RCA
Max. supported	
memory size (USB)	: 32GB
FM frequency range	: 87.5 MHz-108 MHz
BT name	: Zebronics
BT Range	: 10 Meters (Without Obstacles)
BT version	: 4.2
Product dimension (W x D x H)	
Subwoofer	: 17 x 30 x 21.5 cm
Satellite	: 10.5 x 8.5 x 15.5 cm
Net. weight	
Subwoofer	: 3 kg
Satellite	: 350 g x 2
Total	: 3.7 kg

Package Content


Subwoofer	: 1 U
Satellite	: 2 U
Remote	: 1 U
Input Cable	: 1 U
QR Code Guide	: 1 U

Control Panel Description




1. VOLUME CONTROL KNOB
2. TREBLE CONTROL KNOB
3. USB PORT
4. BASS CONTROL KNOB
5. INPUT MODE
6. PREVIOUS / FM CH-
7. PLAY / PAUSE / SCAN
8. LED DISPLAY
9. NEXT / FM CH+

Back Panel Description



Remote Control



Power : standby ON/OFF

Numeric Pad(0-9) : To select particular track from USB drive directly or to enter FM Channel frequency directly

Vol+ : To increase the volume

Prev : To select the previous tracks in BT/USB or to Tune in FM mode

Vol- : To decrease the volume

RPT : To Switch between available repeat modes

Scan : To scan all FM channels available

Mode : Mode Selection (BT/AUX/USB/FM)

EQ : Press to use Equalizer

Play/Pause To Play / Pause the current track. To switch next channel in FM mode

Next : To select the next tracks in BT/USB or to Tune in FM mode

Mute To Mute / Unmute

General Instructions

BT Mode:

Switch the speaker to BT mode, Scan for nearby BT devices in your device. Tap on **"Zebronics"** to connect.

USB Mode:

Insert the USB drive to the speaker. The speaker will detect the USB and the audio files from drive will be played automatically.

FM Radio:

Switch the speaker to FM mode. In FM mode, use the **"SCN"** button in the remote to scan for the available FM channels. Once the scanning is done, the scanned channels will begin to play. The next button or previous button in the remote can be used to change the FM channels.

AUX-IN:

The speaker can be connected to an audio device using an RCA to 3.5mm cable. Connect the one end of the cable to the speaker and the other end to an audio source. The songs from the audio source can be heard through the speaker.

ISO 9001:2015 Certified Company

www.zebronics.com

