



ZEBRONICS
ALWAYS AHEAD

5.1 Speaker

ZEB **FEEL 5**



User Manual

www.zebronics.com

Thank you for purchasing Zebronic Speaker. Please read this user manual carefully before Operation & save it for future reference.

Note:

- Avoid the use of this speaker at the high-temperature and high humidity environment.
- Avoid self-disassemble of speaker, or it will result in the failure of warranty.

Features

5.1 Channel Speaker
Wireless BT/USB/FM/AUX
LED Display
Remote control
10.16cm Subwoofer
Volume, Treble & Bass adjustment
RGB Lights
Stylish Design
Wall Mountable

Specifications

Output Power (RMS)

Subwoofer	: 30 Watts
Satellite	: 10 Watts x 5
Total	: 80 Watts

Driver Size

Subwoofer	: 10.16 cm x 1
Satellite	: 7.62cm x 5

Impedance

Subwoofer : 4Ω

Satellite : 6Ω

Frequency Response : 20Hz - 20kHz

S/N Ratio : ≥80dB

Separation : ≥45dB

File Format Support

(USB) : MP3

Line Input : 2ch RCA

Max. Supported

Memory Size (USB) : 32GB

FM Frequency Range : 87.5 MHz - 108 MHz

BT Name : Zebronics

BT Version : 5.0

Product dimension (W x D x H)

Subwoofer : 150 x 278 x 213 mm

Satellite : 95 x 75 x 205 mm

Net.weight


Subwoofer : 2.72kg

Satellite : 309g x 5


Total : 4.26kg

Control Description


Front Subwoofer Description



Back Subwoofer Description



Remote Control



Power : standby ON/OFF

Numeric Pad (0-9) : To select particular track from USB drive directly or to enter FM Channel frequency directly

Vol+ : To increase the volume

Prev : To select the previous tracks in BT/USB or to Tune in FM mode

Vol- : To decrease the volume

RPT : To Switch between available repeat modes

Scan : To scan all FM channels available

Mode : Mode Selection (BT/AUX/USB/FM)

EQ : Short press to control BASS and short Press again to control TREBLE. Long Press to use Equalizer

Play/Pause To Play / Pause the current track. To switch next channel in FM mode

Next : To select the next tracks in BT/USB or to Tune in FM mode

Mute To Mute / Unmute

General instruction

Bluetooth connectivity

Switch the Speaker to BT mode, Scan for nearby BT devices in your mobile. Tap on BT name **"Zebronics"** to connect.

USB mode

Insert the USB pen drive to the speaker. The speaker will detect the USB & audio from it will be played automatically.

FM Radio

Switch the speaker to FM mode. In FM Mode, Long press the Play / Pause key to scan the available FM channels. Once the scanning is done, the speaker will start playing the first scanned channel. The next and Prev. buttons can be used to change the FM channels.

AUX-IN

The speaker can be connected to an audio device using an RCA to 3.5mm cable. Connect the one end of the cable to the speaker & connect the other end of the cable to an audio source. The songs from the audio source can be heard through the speaker.

ISO 9001:2015 Certified Company

www.zebronics.com

