



2.0 Bookshelf Speaker
BT4848 RUCF



User Manual

www.zebronic.com

Thank you for purchasing the **ZEB-BT4848RUCF** 2.0 Bookshelf speaker. Please read the user manual before usage and save it for future reference.

Note:

- Avoid the usage of this speaker at the high temperature and high humidity environment.
- Avoid the self-disassembly of the product or it results in voiding the product's warranty.
- Turn off the speaker when the speaker is not in use.
- To know more about Terms and conditions for warranty policy,

<https://zebronics.com/pages/warranty-policy>

Features:

BT v5.0 / AUX / FM Radio / USB

2.0 Channel Book Shelf

2-Way Speaker

Headphone Output

Media / Volume Controls

LED Display

Remote Control

LED Light

Specification:

Output Power (RMS) : 80W (40W + 40W)

Driver Size : Woofer - 11.8cm x 2

: Tweeter - 5.08cm x 2

Impedance : Woofer - 4Ω

: Tweeter - 8Ω


Frequency Response : 40Hz-20kHz

S/N Ratio	: $\geq 72\text{dB}$
Separation	: $\geq 40\text{dB}$
File format	
support USB	: MP3
Line input	: AUX
Max supported	
USB memory size	: 32GB
BT Name	: ZEB-BT4848RUCF
BT Version	: v5.0
Product Dimension	
(W x D x H)	: 16.2 x 18.8 x 28.8 cm
Net. weight	: 5.4 kg

Package Content:


Speaker	: 2 U
Remote Control	: 1 U
QR Code guide	: 1 U
Input Cable	: 1 U
FM Antenna Cable	: 1 U

Control Panel Description:



1. USB Input
2. Headphone output
3. Volume knob, Press for EQ modes in BT,USB
4. Previous track/channel
5. Play/Pause, Auto scan
6. Next track/channel
7. Input source mode
8. Left speaker LED connector
9. Line Input
10. Left speaker output
11. FM Antenna
12. Power On/Off

Remote Control



Standby: To awake the power or enable standby mode

Numeric Pad (0-9) : To select direct tracks from / USB drive and select two digits by consecutively pressing

Vol+ : To increase the volume

Prev : To select the previous tracks in BT/USB/ or channels in FM mode

Vol- : To decrease the volume

100+ : To select tracks when more than 100 tracks present in USB

Mode : Mode Selection (BT/AUX/USB/FM)

EQ : Equalizer

Play/Pause : To Play / Pause for current track, Long Press to scan all available FM channels in FM mode

Next : To select the next tracks in BT/USB or channels in FM mode

Mute To Mute / Unmute for currently playing track

General Instruction:

BT Mode:

Switch the speaker to BT mode, Scan for nearby BT devices in your device (Phone, Tablet, etc). Tap on "**ZEB-BT4848RUCF**" to connect.

(Press and hold the play button for 3 seconds to disconnect from existing BT connected device)

USB Mode:

Insert the USB drive to the speaker. The speaker will detect the USB and the audio files from drive will be played automatically.

FM Radio:

Switch the speaker to FM mode. In FM mode, use the "Play/Pause" button in the control panel or remote to scan for the available FM channels. Once the scanning is done, the scanned channels will begin to play. The next button or previous button can be used to change the FM channels.

(Use the provided FM antenna cable for better reception)

AUX-IN:

The speaker can be connected to any audio device using the provided RCA to 3.5mm cable. Connect the red and white RCA cable to the speaker's rear line input ports and the other end to compatible audio source. The audio from the audio source device can be heard through the speaker after changing the mode to AUX.

LED Function:

Press and hold the Input button on the control panel or the remote to activate and deactivate the LED lights on the speaker.

Headphone Output:

Connect the headphone to the 3.5mm AUX output at the back of the speaker. When the headphone is connected the Speakers will be deactivated.

