



Portable BT Speaker

ZEB **ACE**



User Manual

[www.zebronics.com](http://www.zebronics.com)

Thank you for purchasing **ZEB-ACE** Portable BT Speaker. Please read this user manual carefully before operation & save this user manual for future reference.

### **Features:**

Wireless BT

Supports USB & mSD Card

Built-In FM Radio

AUX Input

Media / Volume Control

Wired Mic

Built-in Rechargeable Battery

RGB Lights

### **Specification:**

Output power (RMS) : 8W

BT Version : v5.0

Driver size : 10.2cm

Speaker impedance : 4Ω

Frequency response : 200Hz-20kHz

S/N Ratio : ≥80dB

Max. supported USB/mSD

memory size : 32GB

Supported Audio

formats : MP3

Charging time : 3h


Playback time : 3h\*

Product dimension : 204 x 127 x 304 mm  
(W x D x H)

Net. weight : 870g

*\* at 50% Volume*

## Keys & Ports Description



1. Mode Change Key, RGB On-Off Control Key (Long Press)
2. Volume-/Previous track(in BT/USB/mSD Card Mode) or FM channel
3. Play-Pause/FM Auto Scan Key
4. Volume+/Next Track (in BT/USB/mSD Card Mode) or FM Channel
5. USB Port
6. TF/Micro SD card slot
7. Micro USB Charging Port
8. 3.5mm Mic input
9. On-Off Switch

## **General Instructions:**

### **BT Connectivity**

Turn on the speaker & make sure that the speaker is in BT Mode. Search for nearby BT devices in your mobile & tap on BT name **"ZEB-ACE"** to connect.

### **FM Radio**

Switch the speaker to FM mode. Press the Play-Pause key once to scan the available FM channels. Once the scanning is done the speaker will start playing the first saved FM channel.

### **USB/ Micro SD Card Mode**

When the speaker is ON, insert the USB or Micro SD card to the speaker. It will detect the USB or Micro SD card automatically & start playing the songs from it.

### **AUX Mode**

When the speaker is ON, connect the Micro USB end of the AUX cable to the speaker & connect the other 3.5mm end to a audio source. Now the songs played through the audio source can be heard through the speaker.

### **Charging Instruction**

Connect Micro USB cable to the product & connect the other end of the cable to a 5V DC

adapter.

### **LED Indications:**

**Charging indication:** Red LED glows

**Full charge indication:** Red LED goes OFF

### **Mic Connectivity Instruction**

Connect the included Mic to the 3.5mm Mic input of the speaker. Use the slide switch on the Mic to On/Off the Mic.

***Note:** Connected Mic will work in all mode.*

