

 ZEBRONICS

Portable BT Speaker  
**ZEB** **AXON100**



**User Manual**

[www.zebronoics.com](http://www.zebronoics.com)

Thank you for purchasing the **ZEB-AXON 100** Portable BT Speaker. Please read the user manual carefully before usage & save it for future reference.

**Note:**

- Avoid the usage of this product at high-temperature and high-humidity environments.
- Avoid the self-disassembling of the product or it will result in voiding the Product's warranty.

**Caution:** There is a risk of explosion if the product is disposed in the fire

To know more about Terms and conditions for warranty policy, please visit

<https://zebronics.com/pages/warranty-policy>

**Features:**

- Wireless BT
- AUX Input
- Media / volume control
- Built-in Rechargeable battery
- TWS Function
- RGB LED Lights
- Rapid charging
- Call Function
- Fabric Finish
- IPX5 Water-Resistance


- Carry Handle
- Deep Bass
- 3 EQ Modes

### **Specifications:**

Output Power (RMS)	: 90W
BT Version	: v5.3
Driver Size	
Full Range	: 7.62cm x 2
Tweeter	: 3.81cm x 2
Speaker Impedance	
Full Range	: 4Ω
Tweeter	: 4Ω
Frequency Response	: 60Hz-20kHz
S/N Ratio	: ≥80dB
Max Supported	
USB/mSD memory size	: 64GB
Supported Audio formats	: MP3
Charging time	: 2.5 -4.5h
Playback time	: 6h*
Product Dimension	
(WxD xH)	: 38.5 x 15 x 20 cm
Net. Weight	: 3.08kg

*\* at 50% volume (LED off) - Default EQ*

## Port & Button Description:



1. AUX Port
2. USB Port
3. Type-C Charging Jack
4. Backward/Volume Down
  - Short press to decrease the volume
  - Long press to move to previous Track
5. Forward/Volume Up
  - Short press to increase the volume
  - Long press to move to Next Track
6. Play/Pause
  - Short press to Play or Pause the Track
7. EQ Button
  - Short press to Switch between the Three Equalizer mode.
8. RGB Light
  - Short press to Switch between the LED modes

## 9. Mode Button

- Short press to Switch between modes
- Long press to Enable TWS mode

## 10. Power Button

- Long press to Turn ON/ OFF the Speaker.

## 11. Charging Indicator

## 12. Built-in Microphone

# General Instructions

### **BT Mode:**

Switch on the speaker to BT mode, Scan for nearby BT devices in your device. Tap on **“ZEB-AXON 100 ”** to connect.

### **USB Mode:**

Insert the USB Drive to the USB port, the speaker will detect the USB Drive and the audio file will be played automatically.

### **AUX-IN:**

The speaker can be connected to an audio device using a 3.5mm cable. Connect the one end of the cable to the speaker & connect the other end of the cable to an audio source. The tracks from the audio source can be heard through the speaker.

## **TWS Connectivity:**

When two speaker are in Bluetooth mode, long press "M" button of one speaker to enter TWS mode, It will search automatically, when two speakers connected successfully, you can control two speaker at the same time.

*Note: Requires two speakers for TWS feature*

## **Call Function:**

Connect the Speaker to your mobile device.

- Short press the Play/ pause button to attend the call.
- Long press the Play/ Pause button to reject the call.

## **During the call,**

- Short press the Play/Pause button to switch to mobile phone.
- Long press the Play/Pause button to End the call.

## **Charging Instruction:**

Connect the charging cable to a DC5V adaptor and connect the other end to the speaker.while charging a Red LED will glow and the LED goes OFF once the speaker is fully charged.

ISO 9001:2015 Certified Company  
[www.zebronics.com](http://www.zebronics.com)

