



ZEBRONICS
ALWAYS AHEAD

Portable BT Speaker

BARREL

100



User Manual

www.zebronics.com

Dear Consumer,

Thank you for purchasing ZEB-BARREL 100 Portable Speaker. Please read the user manual carefully before usage & save it for future reference.

Note:

- Avoid the usage of this product at the high temperature and high humidity environment.
- Avoid the self-disassemble of the product as it results in the failure of Warranty.
- Turn off the speaker if the speaker is not being used for a long period of time.

Features:

Wireless BT

Supports USB & mSD

Built-in FM Radio

AUX Input

TWS Function

6.3mm Microphone input

Media / Volume control

Built-in Rechargeable battery

Specifications :


Output Power (RMS)	: 20W
BT Version	: v5.0
Driver Size	: 16.51cm
Speaker Impedance	: 2.2Ω
Frequency Response	: 100Hz-20kHz
S/N Ratio	: ≥80dB
Max. Supported USB / mSD memory size	: 32GB
Supported Audio formats	: Mp3
Charging time	: 3h
Playback time	: 6h*
Product dimension (Dia x H)	: 213 x 300 mm
Net. weight	: 1.9kg

Package contents :

Speaker	: 1 U
Charging cable	: 1 U
Wired Mic	: 1 U
Aux cable	: 1 U
QR Code Guide	: 1 U

**at 50% volume (LED OFF)*

Buttons & Ports Description



- | | | |
|------------------------|------------------|---------------|
| 1 RGB Light Button | 5 Next/Volume Up | 9 USB |
| 2 Mode | 6 Bass Button | 10 Micro SD |
| 3 Previous/Volume Down | 7 Power On/Off | 11 Mic in |
| 4 Play/Pause | 8 AUX in | 12 DC in (5V) |

Button Function :

Power On/off

Use the Power ON/OFF slider switch to Switch On/Off the speaker.

BT Mode :

- Once the speaker is on, Please make sure that the speaker is in BT mode.
- Now, search for nearby BT device in your mobile and Tap on the BT name ZEB-BARREL 100 to connect.
- Short-press "+" or "-" to control the media.
- Long-press "+" or "-" to adjust the volume.
- Short press "Play/Pause" to Play/Pause the music.

USB / Micro SD card Mode :

- Once the speaker is ON, Insert a USB pen drive / Micro SD card to the respective port of the speaker.
- The speaker will automatically detect the songs from the USB drive / Micro SD card and play.
- Long-press "+" or "-" to adjust the volume
- Short press "Play/Pause" to Play/Pause the music.

FM Radio :

- Once the speaker is turned ON, Please switch the speaker to FM mode using the Mode button.
- Press the "Play/Pause" key to auto scan the available FM channels.

- Short-press “+” or “-” to change the scanned FM channels
- Long-press “+” or “-” to adjust the volume

Note : Please use Aux cable as antenna for better FM signal reception.

TWS Function :

- Turn on two ZEB-BARREL 100 speakers you want to pair
- Long press the "M" button on any one speaker to activate TWS mode.
- After Few seconds, both the speakers will be connected successfully.
- Now, search for nearby BT device in your mobile and Tap on the BT name ZEB-BARREL 100 to connect.
- To exit TWS mode, long Press "M" button again.

Note: Users need to make TWS connection first, then make Bluetooth connection with the mobile phone.

AUX-IN:

Switch the speaker to AUX Mode, Connect one end of the AUX Cable to the speaker & connect the other end to an audio source. The songs played from the audio source can be heard through the speaker.

Charging instruction:

Connect the micro USB to the speaker & connect the other end of the cable to a DC 5V adapter.

