



ZEBRONICS
ALWAYS AHEAD

Portable BT Speaker

BEEN **BUDDY**
100



User Manual

www.zebronics.com

Dear Consumer,

Thank you for purchasing ZEB-BUDDY 100 Portable Speaker. Please read the user manual carefully before usage & save it for future reference.

Note:

- Avoid the usage of this product at the high temperature and high humidity environment.
- Avoid the self-disassemble of the product as it results in the failure of Warranty.
- Turn off the speaker if the speaker is not being used for a long period of time.

Features

Wireless BT

Supports USB & Micro SD Card

Built-in FM Radio

AUX input

TWS Function

Media / Volume control

6.3mm Microphone input

RGB Lights with multiple modes

Built-in Rechargeable battery

Specifications

Output Power (RMS) : 15W

BT Version : v5.0

Driver Size : 10.16 cm

Speaker Impedance : 3Ω

Frequency Response : 100Hz-20kHz


S/N Ratio	: $\geq 80\text{dB}$
Max. Supported USB / micro SD memory size	: 32GB
Supported audio formats	: Mp3
Charging time	: 3.5 H
Playback time	: 5H*
Product dimension (W x D x H)	: 155 x 150 x 230 mm
Net. weight	: 1.1kg


Package contents

Speaker	: 1 Unit
Wired Mic	: 1 Unit
Charging cable	: 1 Unit
AUX cable	: 1 Unit

**at 50% volume (LED OFF)*

Buttons & Ports Description





- | | | |
|------------------------|------------------|---------------|
| 1 RGB Light Button | 5 Next/Volume Up | 9 USB |
| 2 Mode | 6 Bass | 10 Micro SD |
| 3 Previous/Volume Down | 7 Power On/Off | 11 Mic in |
| 4 Play/Pause | 8 AUX in | 12 DC in (5V) |

Button Function:

Power On/off

Use the Power ON/OFF slider switch to Switch On/Off the speaker.

BT Connectivity

- Once the speaker is on, Please make sure that the speaker is in BT mode.
- Now, search for nearby BT device in your mobile and Tap on the BT name "**ZEB-BUDDY 100**" to connect.
- Short-press "+" or "-" to control the media.
- Long-press "+" or "-" to adjust the volume.
- Short press "**Play/Pause**" to Play/Pause the music.

USB / Micro SD card Mode

- Once the speaker is ON, Insert a USB pendrive / Micro SD card to the respective port of the speaker.
- The speaker will automatically detect the songs from the pen drive / Micro SD card and play.
- Short press "+" or "-" to control the media
- Long press "+" or "-" to adjust the volume
- Short press **"Play/Pause"** to Play/Pause the music

FM Radio

- Once the speaker is turned ON, Please switch the speaker to FM mode using the Mode button.
- Short press the **"Play/Pause"** key to auto scan the available FM channels.
- Short press "+" or "-" to change the scanned FM channels
- Long press "+" or "-" to adjust the volume

***Note:** Please use charging cable as antenna for better FM signal reception.*

TWS Function

- Turn on two ZEB-BUDDY 100 speakers you want to pair.
- Long press the **"M"** button on any one speaker to activate TWS mode.

- After Few seconds, both the speakers will be connected successfully.
- Now, search for nearby BT device in your mobile and Tap on the BT name **"ZEB-BUDDY100"** to connect.
- To exit TWS mode, long Press **"M"** button again (in any one of the speaker).

***Note:** Users need to make TWS connection first, then make Bluetooth connection with the mobile phone.*

AUX-IN:

Switch the speaker to AUX Mode, Connect one end of the AUX Cable to the speaker & connect the other end to an audio source. The songs played from the audio source can be heard through the speaker.

RGB Light Control

When the speaker is turned on, the RGB light is on automatically, user can switch the light modes using the "Bulb Icon" switch.

Charging instruction

Connect Micro USB cable to the speaker & connect the other end of the cable to a DC 5V adapter.

ISO 9001:2015 Certified Company
www.zebronics.com

