



Portable BT Speaker

**ZEB** **CONGA**



**User Manual**

[www.zebronics.com](http://www.zebronics.com)

Thank you for purchasing **ZEB-CONGA** (Portable BT Speaker). Please read this user manual carefully before operation & save this user manual for further reference.

Note:

- Avoid the usage of this product at the high temperature and high humidity environment.
- Avoid the self-disassembly of the products or it results in voiding the product's Warranty.
- Avoid using the speaker while charging.

To know more about Terms and conditions for warranty policy, please visit

*<https://zebronics.com/pages/warranty-policy>*

### **Features:**

Wireless BT v5.0 / USB / mSD / FM / AUX

Media / Volume control

Call Function

Dual Drivers

Built-in Rechargeable battery

TWS Function

Fabric Finish


Model	: ZEB-PSPK 27
Output Power (RMS)	: 8W
BT Version	: 5.0
BT Name	: ZEB-CONGA
Driver Size	: 5.2cm
Speaker Impedance	: 4Ω
Frequency Response	: 100Hz-18kHz
S/N Ratio	: ≥70dB
Max Supported USB/mSD memory size	: 32GB
Supported Audio formats	: Mp3
Charging time	: 4h
Playback time	: 6h*
Product Dimension (Dia. x H)	: 7.5 x 16.2cm
Net. Weight	: 432g

\* at 50% Volume (LED OFF)


### **Package Contents**

Speaker	: 1 U
Charging cable	: 1 U
QR Code Guide	: 1 U

## Product Button & Port Representation:



- 1) Volume increase / Next Track
- 2) Volume Decrease / Previous Track
- 3) Microphone
- 4) Play, Pause / Redial / Call Attend, Call reject
- 5) Mode / TWS
- 6) Power On/Off



## **Usage Instruction:**

### **Button Functions:**

- Press and hold the Power button for 2 seconds to Power On/Off
- Short press the Play/Pause button to Play or Pause playback also to accept incoming call or End the ongoing call
- Double press the Play/Pause button to initiate Redial function
- Short press the (+) button to increase the volume
- Short press the (-) button to decrease the volume
- Press and hold the (+) button for next track
- Press and hold the (-) button for previous track
- Short press the (M) button to change the source modes
- Long press the (M) button to enable TWS function

*(The above functions are common for USB & mSD)*

### **BT Pairing Instructions:**

- The speaker enters BT pairing mode automatically after it's powered on or switched to BT mode

- Turn ON the BT in your mobile device settings & search for the BT name "**ZEB-CONGA**"
- Once the BT name is visible in your mobile settings, tap on it and click pair to connect.

### **FM Radio:**

- Short press Play/Pause button to auto scan the available FM channels.
- Long press (+/-) button to change auto scanned FM stations.

### **Charging instruction:**

- Use the provided micro USB charging cable to any DC 5V rated USB output.

### **LED Functions:**

- Red light glows – Charging
- Red light turns off – Fully charged
- Blue light blinks – BT discovery mode
- Blue light glows constant – BT paired successfully

