



**ZEBRONICS**  
ALWAYS AHEAD

Portable BT Speaker  
**ZEB DAWN 10**



**User Manual**

[www.zebronics.com](http://www.zebronics.com)

Thank you for purchasing **“ZEB-DAWN 10” portable BT speaker**. Please read this user manual carefully before operation & save it for future reference.

**Note:**

- Avoid the use of this product at the high-temperature and high humidity environment.
- Avoid self-disassembly of product, or it will result in the Voiding the product’s warranty.
- Please charge the product with power adaptor output rated voltage DC 5V 1A.

**Features:**

BT v5.0

Supports USB

Built-in FM Radio

AUX Input

TWS Function

Media / Volume control

Built-in Rechargeable battery

Cliff Design RGB Fusion

11 LED Modes + 1 OFF Mode

**Specifications:**

Output power (RMS) : 8W

BT version : 5.0

Driver Size : 7.62cm


Speaker Impedance	: 3Ω
Frequency Response	: 90Hz-20kHz
S/N ratio	: ≥60dB
Max. supported USB memory size	: 32GB
Supported audio formats	: MP3/WAV/WMA
Charging time	: 3h
Playback time	: 14h*
Product dimension (Dia x H)	: 11.8 x 13.6 cm
Net. weight	: 495g

### **Package Contents**

Speaker	: 1 U
Charging Cable	: 1 U
QR Code Guide	: 1 U

*\* at 50% Volume (LED OFF)*

## Button Description:



### 1. **Power ON-OFF / Play-Pause /TWS Button**

Single press to play & Pause Track

Double press to Switch TWS Function

Press & Hold to Power ON/OFF

### 2. **Previous Button -**

Single press to Previous Track in

USB/BT & FM channel in FM mode.

Press & Hold to Volume Down

### 3. **Next Button -**

Single press to Next Track in

USB/BT & FM channel in FM mode.

Press & Hold to Volume Up

### 4. **Input mode / LED Lights Button**

Single Press mode button to change input modes.

Long Press mode/ LED Button to Change LED Modes.

### 5. **AUX In**

### 6. **USB Port**

### 7. **LED Indicator**

### 8. **Type C Charging port**

## **Charging the Speaker**

1. Connect the Type-C charging cable to the DC 5V charging port of the speaker and insert the other end into a USB power adaptor with minimum DC 5V 1A power rating.
2. Battery indicator LED glows, indicating that the battery is being charged. The LED will turn off when the battery is fully charged.

## **LED Modes**

- >Double press the RGB button to turn it off,
- >Press & hold down the RGB LED button to change the led modes.

## **BT mode**

1. Switch the Input mode to BT on your "ZEB-DAWN 10"
2. Turn ON BT on your phone / tablet and search for nearby BT devices.
3. Search for the BT name "ZEB-DAWN 10" and tap to connect it.

## **USB mode**

1. Connect the USB Flash drive into the USB port of the speaker. The Speaker would automatically detect the plugged USB drive and Plays the audio files of the USB.

## **FM Radio**

Switch the speaker to FM mode. Double press PLAY/PAUSE button to scan for the available FM channels.

Once the scanning is done, the scanned channels will begin to play. Use Prev/next button to change the FM channels.

## **AUX Mode**

Connect the speaker to an audio source (phone, TV, PC) using 3.5mm cable. Once connected, change the speaker to AUX mode and thereafter audio can be streamed via the speaker from the connected audio source.

## **TWS(True Wireless Stereo) function**

When two speakers are in Bluetooth mode, double press the “power button” on one of the speaker to enter TWS mode, it will automatically search for the other speaker and connects with the other speaker automatically, when two speakers connected successfully, you can control two speakers at the same time.

***Note:** Requires two ZEB-DAWN 10 speakers for TWS feature.*

*Buy another ZEB-DAWN 10 Speaker to Enable TWS Features”*

**ISO 9001:2015 Certified Company**

**[www.zebronics.com](http://www.zebronics.com)**

