



ZEBRONICS
ALWAYS AHEAD

Portable BT Speaker
ZEB DELIGHT 20



User Manual

www.zebronics.com

Dear Consumer,

Thank you for purchasing **ZEB-DELIGHT 20** Portable BT Speaker. Please read the user manual carefully before usage & save it for future reference.

Note:

- *Avoid the usage of this product at the high temperature and high humidity environment.*
- *Avoid the self-disassemble of the product as it results in the failure of Warranty.*
- *Turn off the speaker if the speaker is not being used for a long period of time.*

Features

Wireless BT

Supports USB & micro SD

Built-in FM Radio

AUX Input

TWS Function

Call Function

Media / Volume control

Built-in Rechargeable battery

RGB Lights

Specifications

Output Power (RMS) : 10W (5W + 5W)

BT Version : 5.0

Driver Size : 52mm x 2

Speaker Impedance : 3Ω

Frequency Response : 80Hz-18kHz


S/N Ratio	: ≥85dB
Max Supported USB & micro SD memory size	: 32GB
Supported	
Audio formats	: MP3
Charging time	: 3H
Playback time	: 5H*
Product Dimension (W x D x H)	: 200 x 67 x 79 mm
Net. Weight	: 457g

Package Contents


Speaker	: 1 unit
Charging cable	: 1 unit
Input cable	: 1 unit

**at 50% volume (LED OFF)*

Buttons Descriptions:







- 1 Previous/Volume Down
- 2 Play/Pause
- 3 Next/Volume Up
- 4 Mode
- 5 Call attend / Reject
- 6 USB Port
- 7 Micro USB/Charging Port
- 8 AUX Port
- 9 On/Off Switch
- 10 Micro SD Slot



Instruction for Use

Button Function:

1. Turn the speaker On/Off using the slider power switch.
2. Short press the " **M** " button to switch the modes.
3. Long press the " **+/-** " buttons to increase / decrease the volume.
4. Short press the " **+/-** " buttons to change the NEXT/PREV tracks.
5. Single press the "  " to Play/Pause the track being played.
6. During Calls, Press the "  " button to attend/end call. Long press the "  " button to reject the incoming call.
7. Double press "  " button to redial.


Pairing with the BT speaker:

1. Power ON the Speaker and you will hear the indication for the BT mode.
2. Switch ON BT on your phone or tablet and search for the nearby BT devices.
3. Search for the BT name "**ZEB-DELIGHT 20**" and tap to connect it.

Micro SD / USB Mode:

Connect the micro SD card / USB drive to the respective ports of the **ZEB-DELIGHT 20** and the speaker will automatically start playing from the micro SD card / USB drive.

FM Radio:

- Once the speaker is turned ON, Please switch the speaker to FM mode using the Mode button.
- Short press the “  ” key to auto scan the available FM channels.
- Short-press “+” or “-” to change the scanned FM channels
- Long-press “+” or “-” to adjust the volume.

Note: Please use Aux cable as antenna for better FM signal reception.

AUX-In:

Switch the speaker to AUX mode. Connect one end of the AUX cable to the speaker & connect the other end to an audio source. The songs played from the audio source can be heard through the speaker.

TWS Function:


- Turn on two **ZEB-DELIGHT 20** speakers you want to pair.
- Long press the “Mode” button on any one speaker to activate TWS mode.
- After few seconds, both the speakers will be connected successfully.
- Now search for nearby BT device from your mobile and tap on the BT name “**ZEB-DELIGHT 20**” to connect.

- To exit TWS mode, long press "MODE" button again.

Charging the Speaker:

1. Connect the charging cable to Micro USB port of the speaker and insert the other end into a DC 5V charging power source/adaptor.
2. Red LED glows indicating that the battery is being charged.

LED Light Control

Long press "  " key to turn the LED ON/OFF.

