



ZEBRONICS
ALWAYS AHEAD

Portable BT Speaker
ZEB **ROCKET** 500



User Manual

www.zebronics.com

Dear Customer,

Thank you for purchasing **ZEB-ROCKET 500** Portable Speaker. Please read the user manual carefully before usage & save it for future reference.

Features

Wireless BT / USB / FM / AUX

RGB Light

Deep Bass

Type C Charging

Volume & Media controls

Dual 76.2mm Drives

Built-in Rechargeable battery

Microphone input

TWS Function

Detachable Carry handle

Dual Passive radiator

Specifications

Output Power : 20W (10W+10W)

BT Version : 5.0

Driver Size : 76.2mm x 2

Speaker Impedance : 4Ω

Frequency Response : 80Hz-16kHz

S/N Ratio : ≥85dB

Max Supported USB

memory size : 32GB

Supported

Audio formats : MP3, WAV, WMA

Charging time : 3h


Playback time	: 6h*
Product Dimension (W x D x H)	: 33.2 x 14.2 x 15.2 cm
Net. Weight	: 1.75 kg

Package Contents

Speaker	: 1 U
Charging cable	: 1 U
AUX cable	: 1 U
QR Code Guide	: 1 U

** at 50% volume level (LED off)*

Button & Port Description



1. LED Display
2. Volume Control Knob
3. Previous Track / FM Channel -
4. Play / Pause, LED ON/OFF (Long Press), Scan Channels in FM Mode (Long Press)
5. Next Track / FM Channel +
6. Mode Change (Short Press), TWS Function (Long Press)
7. Power ON/OFF (Long Press) with LED Indicator
8. MIC Input
9. AUX Input
10. Reset
11. USB
12. Type-C Charging Port

Button Function:



Power On/off

- Long-press the Power button to turn the speaker on and off.

Bluetooth

- Once the speaker is on, Please make sure that the speaker is in BT mode.
- Now, search for nearby BT device in your mobile and Tap on the BT name **ZEB-ROCKET 500** to connect.

TWS Function

- Turn on two **ZEB-ROCKET 500** speakers you want to pair
- Long press the “  ” button on any one speaker to activate TWS mode.
- Now, search for nearby BT device in your mobile and tap on the BT name **ZEB-ROCKET 500** to connect.
- To exit TWS mode, Long Press “  ” button again.

***Note:** Users need to make TWS connection first, then make Bluetooth connection with the mobile phone.*




AUX IN

Switch the speaker to AUX Mode, Connect one end of the AUX Cable to the speaker & connect the other end to an audio source. The songs played from the audio source can be heard through the speaker.

USB mode

Connect the USB device to the respective ports of ZEB-Rocket 500 speaker and the speaker would automatically start playing from the USB device.

FM Radio mode

- Short press “  ” button can switch to FM mode. Once the speaker is in FM mode.
- Long press the “  ” button once to start scanning for FM channels.
- Once scanning is complete, short press the “  ” button to change the channels.


Charging instruction

Connect Type C cable to the speaker & connect the other end of the cable to a 5V DC adapter.

Note:

- *Don't keep the speaker near places which are at high temperature.*
- *Don't open the speaker in order to avoid electrical shock & other accidents*
- *Turn off the speaker if the speaker is not being used for a long period of time*

RGB Light ON/OFF

The RGB Light is turned on when speaker is powered on, user can Long Press  button to turn the Light OFF and ON.

Manual RESET (to be done only if required)
and Pairing Procedure:

- Single Press the RESET button (Using a Pin), which automatically Reset and Restart the Speaker.
- Once the Speaker is ON, the pairing will initiate automatically.

