



Portable BT speaker

ZEB **SONIC POD15** *Plus*



User Manual

www.zebronics.com

Dear Customer,

Thank you for purchasing **ZEB-SONIC POD15 Plus** (Portable BT Speaker). Please read the user manual carefully before usage & save it for future reference.

Note:

- *Avoid the usage of this product at the high temperature and high humidity environment.*
- *Avoid the self-disassembly of the products or it results in the voiding the product's Warranty.*
- *Turn off the speaker when the speaker is not in use.*
- *To know more about Terms and conditions for warranty policy, please visit*

<https://zebronics.com/pages/warranty-policy>

Features:

- 8W RMS
- Upto 5h* backup
- 9 RGB Modes
- Passive radiator
- TWS function
- Fabric Finish
- Splash Proof
- Carry loop
- BT v5.4 | USB | mSD

- Media / Volume control
- Call Function
- Type-C Charging
- Built-in battery

Specifications:


Output Power (RMS)	: 8W
Material	: Fabric + ABS
BT Version	: v5.4
Driver Size	: 6.6cm
Passive Radiator Size	: 7.8cm
Speaker Impedance	: 3Ω
Frequency Response	: 100Hz-20kHz
S/N Ratio	: ≥75dB
Max Supported USB/mSD memory size	: 32GB
Supported Audio formats	: MP3
Charging time	: 4.5h
Playback time	: 5h*
Product Dimension (Wx D x H)	: 10.6 x 10.6 x 13.2cm
Net. Weight	: 504g

* (LED Off)


Package Contents:

Speaker	: 1 U
Charging cable	: 1 U
QR Code Guide	: 1 U

Button & Port Description:



- ① Volume Increase
- ② Power Button
- ③ Mode Button
- ④ Volume Decrease



- ① USB Port
- ② Type-C Charging Port
- ③ Led Indicator
- ④ mSD Port

Instruction for Use:

Button Function:

- Long press the Power button to turn the speaker On/Off. Short press the Power button to Play or Pause audio playback.
- Double-press the Power button to automatically call the most recently dialed outgoing number.
- To increase the volume of the speaker, short press the Volume Increase Button.

Long press this button to change to next tracks/channels.

- To decrease the volume of the speaker, Short press the Volume Decrease Button. Long press this button to change to previous tracks/channels.
- To change between different input modes of the speaker, Short press the Mode Button. Long press this button will change between different LED modes of the speaker.

Pairing with the BT speaker:

- Power ON the Speaker and you will hear the indication for the BT mode.
- Switch ON BT on your phone or tablet and search for the nearby BT devices.
- Search for the BT name **“ZEB-Sonic Pod 15 Plus”** and tap to connect it.

Micro SD / USB Mode:

Connect the micro SD card / USB drive to the respective ports of the **ZEB-SONIC POD 15 Plus** and the speaker will automatically start playing from the micro SD card / USB drive.

FM Radio:

- Once the speaker is turned ON, Please switch the speaker to FM mode using the Mode button.

- Once the speaker is in FM mode then Long press the Volume increase Button to scan between different channels.

TWS Function:

- Turn on two ZEB-SonicPod 15 Plus speakers you want to pair.
- Double press the Mode button speaker to activate TWS mode.
- After a few seconds, both the speakers will be connected successfully.
- Now search for a nearby BT device from your mobile and tap on the BT name **"ZEB-SonicPod 15 Plus"** to connect.
- To exit TWS mode, Short press the MODE button again.

Note: *Requires two ZEB-SONIC POD 15 Plus speakers for TWS feature.*

Charging the Speaker:

- Connect the charging cable to the Type-C Charging Port of the speaker and insert the other end into a DC 5V charging power source/adaptor.
- Red LED glows indicating that the battery is being charged.
- Once the battery is fully charged, the Red LED will turn off automatically.