



Portable BT Speaker

ZEBSONIC PODS



User Manual

www.zebronics.com

Dear Customer,

Thank you for purchasing **ZEB-SONIC POD S** Portable BT Speaker. Please read the user manual carefully before usage & save it for future reference.

Note:

- *Avoid the usage of this product at the high temperature and high humidity environment.*
- *Avoid the self-disassembly of the products or it results in voiding the product's Warranty.*
- *Charge the speaker with the DC 5V input rated power adapter.*
- *To know more about Terms and conditions for warranty policy, please visit*

<https://zebronics.com/pages/warranty-policy>

Features

BT v5.3 | mSD | AUX

Call Function

Compact Design with Carry Loop

Passive Radiator

Compact & Stylish

TWS Function

Type-C Charging

Specifications

Output Power (RMS) : 8W

BT Version : v5.3

Driver Size : 45 mm

Speaker Impedance : 4Ω

Frequency Response : 100Hz-20kHz


S/N Ratio	: ≥70dB
Max. Supported Memory Size	: 32GB (mSD)
Supported Audio Formats	: MP3
Charging Time	: 2h
Playback Time	: 12h*
Product Dimension	: 10.6 x 3.6 x 6.2 cm (W x D x H)
Net. Weight	: 230g

** at 60% volume level*

Package Contents

Speaker	: 1 U
Charging Cable	: 1 U
QR Code Guide	: 1 U

Product Details



1. Carry Loop
2. Power Button for ON/OFF
3. Short press to Play / Pause & Long press to TWS Pair/Unpair
4. Volume Decrease
5. Volume Increase
6. Input Modes
7. Charging LED Indicator (RED LED while Charging & LED goes Off after Full Charged)
8. mSD Slot
9. Type-C Charging Port
10. Aux Input

Usage Instruction:

BT Mode:

Switch on the BT on your mobile phone or other source device and search for BT name **ZEB-SONIC POD S** and tap to connect your source device with speaker. Once the BT source device is successfully connected to the speaker the white LED flashing on the front will glow constantly.

Micro SD Mode:

The Speaker automatically switches to mSD mode when the card is inserted to the slot and start playing the music from the card automatically.

AUX Mode:

Plug the 3.5mm input cable to the speaker and plug other end to any compatible output device & play music through aux. (Note : Media controls can be controlled only via the source device).

TWS Mode:

For TWS Mode you need two "**ZEB-Sonic pod S**" speakers, Follow bellow instruction for TWS pairing.

Step 1 : Both the speakers should be kept in BT Mode. (Indicated by flashing white LED on front panel).

Step 2 : Long press the Play/Pause button on any one of the speaker you will hear voice prompt saying TWS Mode.

Step 3 : After 5 seconds both speakers will get connected automatically.

Step 4 : Open BT settings on your source device connect to the BT name **ZEB-SONIC POD S**

once successfully connected, you can hear your source music on both the speakers.

Note : *To exit TWS mode long press the play/pause button on any one of the speaker.*

ISO 9001:2015 Certified Company
www.zebronics.com

