

ZEBRONICS

Portable BT Speaker

ZEB **SOUND**
FEAST **270**



User Manual

www.zebronics.com

Dear Customer,

Thank you for purchasing the **"ZEB-SoundFeast 270"** Portable BT Speaker. Please read this user manual carefully before usage and save it for further reference.

Note:

- *Avoid the usage of this product at the high temperature and high humidity environment.*
- *Avoid the self-disassemble of the product as it results in the failure of Warranty.*
- *Turn off the speaker if the speaker is not being used for a long period of time.*
- *To know more about Terms and conditions for warranty policy, please visit*

<https://zebronics.com/pages/warranty-policy>

Features:

- 60W RMS
- Up to 6h* backup
- Dual 78mm Drivers
- Dual Passive Radiator
- TWS Function
- Splash Proof
- BT v5.3 | USB | AUX
- Call Function
- Voice Assistant Support
- Multicolor LED Lights
- Media / Volume Control
- Fabric Finish

- Type-C Charging
- Built-in Battery

Specifications:


Model ID	: ZEB-SSPK 8
Output Power (RMS)	: 60W
BT Version	: v5.3
Driver Size	: 7.8cm x 2
Speaker Impedance	: 4Ω
Frequency Response	: 80Hz-20kHz
S/N Ratio	: ≥75dB
Max Supported	
USB Memory Size	: 32GB
Supported Audio formats:	MP3
Charging Time	: 7h
Playback Time	: 6h*
Product Dimension	: 22.8 x 12.2 x 17.5 cm (W x D x H)
Net.Weight	: 1.4 kg

**at 70% Volume (LED OFF)*

Package Contents :

Speaker	: 1 U
Type-C Cable	: 1 U
Input cable	: 1 U
QR Code Guide	: 1 U

Product & Port Description:



Instructions for Button Use:

- Long Press the Power Button to Turn On | Off the Speaker.
- Short Press the Volume - | Volume + Button to decrease or increase the volume of the Speaker & Long Press the respective buttons for Previous | Next Track.
- Short Press the TWS Button to enable TWS Function and Long Press to disable the TWS Function.
- Short Press the Play | Pause Button to play or pause the tracks. Short Press the button to attend or decline the receiving calls. Long Press the button to Reject the call.
- Short Press the RGB LED Button to change the RGB Modes and Long Press to activate Voice Assistant Feature.
- Short Press the Mode Button to toggle between the Modes of the Speaker.

General Instructions:

BT Mode

- Turn ON the speaker using the Power Button.
- Turn ON BT on your phone / tablet and search for nearby BT devices.
- Search for the BT name "**ZEB-SoundFeast 270**" and tap to connect it.

USB Mode:

Connect the USB drive in to the respective port of "**ZEB-SoundFeast 270**" and the speaker would automatically start playing from the USB drive.

AUX-IN:

Connect the speaker to an audio source (Phone, TV, PC) using 3.5mm cable. Once connected AUX IN mode will automatically be chosen and thereafter audio can be streamed via the speaker from the connected source.

TWS Mode:

Turn on both **ZEB-SoundFeast 270** Speakers. Make sure that the speakers are in BT Mode. Short Press the TWS Button on any one of the speakers to activate TWS mode. Now, the speaker will automatically connect to each other.

Now search for nearby BT devices in your mobile and tap on the BT name **ZEB-SoundFeast 270** to connect.

Note: Requires two speakers for the TWS feature

Charging Instruction:

Connect the charging cable to a DC 5V Adapter. A Red LED would glow while charging & the LED would turn OFF once charging is complete.

