



Portable BT Speaker
STARLIT



User Manual

www.zebronics.com

Thank you for purchasing **ZEB-STARLIT** Portable BT Speaker. Please read this user manual carefully before operation & save it for future reference.

Note:

- *Avoid the use of this product at the high temperature and high humidity environment.*
- *Avoid self-disassembly of the products or it results in the voiding the product's Warranty.*
- *To know more about Terms and conditions for warranty policy, please visit*

<https://zebronics.com/pages/warranty-policy>

Features:

BT v5.3 | USB | mSD | FM | AUX | MIC IN x 2

Karaoke Function

LED Display

RGB lights

Dual Full Range 16.51cm

Remote control

Wireless mic

Built-in Rechargeable Battery

TWS Function

Volume, Treble, Bass, Mic Vol, Echo Controls

Specifications:

Model : ZEB-DSPK 106

Output Power (RMS) : 70W

Driver Size : Full range -16.51cm x 2
Tweeter - 5.08cm

Speaker Impedance	: Full range - 4Ω Tweeter - 4Ω
Frequency Response	: 60Hz-20KHz
S/N Ratio	: ≥85dB
File format support	
(USB/mSD)	: Mp3
Line input	: 3.5mm
Max. Supported	
USB/mSD	
Memory Size	: 32GB
FM frequency range	: 87.5 MHz - 108 Mhz
Charging Time	: 6h
Playback Time	: 6h*
BT name	: ZEB-STARLIT
BT Version	: v5.3
Product Dimension	: 26.5 x 29.5 x 61 cm
(W x D x H)	
Net. Weight	: 6 Kg


** at 50% Volume (LED off)*

Package Contents:

Speaker	: 1 U
Remote	: 1 U
Wireless Mic	: 1 U
Power adapter	: 1 U
Input Cable	: 1 U
QR Code Guide	: 1 U


Product Description:

Control Panel Descriptions



- 1.LED Display
- 2.Power Switch
- 3.TF Card Slot
- 4.USB Port
- 5.Previous
- 6.Play/Pause/LED
- 7.Next
- 8.Volume Down
- 9.Volume Up
- 10.Mode/TWS
- 11.Menu/M.Pri
- 12.REC
- 13.Charging Port
- 14.Charging Indicator
- 15.Mic 1 & Mic 2
- 16.Aux Port

Remote Control



- | | |
|-----------------|----------------------|
| 1. Power Button | 8.TWS |
| 2. Mute/Unmute | 9.Vol + |
| 3. EQ | 10.Next |
| 4. Mode | 11.Vol - |
| 5. Bass - | 12.Play/Pause |
| 6. Bass + | 13.Previous |
| 7. LED | 14.Numeric Pads(0-9) |

General Instructions :

BT Connectivity :

Switch the source to BT mode Turn on BT on your mobile and scan for nearby BT devices.

Tap on "**ZEB - STARLIT**" to connect.

FM Radio :

Switch the speaker to FM mode

Long press the Play/Pause button to scan the available FM channels.

Once the scanning is done, the first scanned channel will start playing.

USB/Micro SD card Mode :

Insert the USB/Micro SD card into the slot provided on the speaker.

The speaker will automatically detect the USB/Micro SD card and the supported audio content will be played from it.

Note: This mode isn't selectable on the speaker or remote control unless a USB/mSD flash card is connected.

AUX-In :

The speaker can be connected to an audio source using a 3.5mm cable.

Connect one end of the cable to the AUX-In port on the speaker and the other end an audio source.

The audio from the source can be Played through the speaker.

TWS Mode :

Switch on two **"ZEB-STARLIT"** speakers you want to pair & enter BT mode on both the speakers. (don't connect to any of the BT source device).

Now in any one of the speaker press the TWS button on panel or single press on remote to initiate the TWS pairing automatically It gets connected to the secondary speaker.

Now open the BT settings on your mobile phone or other source device, search for BT name **"ZEB-STARLIT"** and tap to connect.

Charging Indication :

Red LED on the Top panel of the speaker glows. Once the speaker is fully charged the RED LED Light will gets off .

