

Portable BT Speaker  
**VITA102**  
ZEB

**User Manual**

[www.zebronics.com](http://www.zebronics.com)

Dear Customer,

Thank you for purchasing **ZEB-VITA 102** Portable BT Speaker. Please read this user manual carefully before operation & save it for future reference.

**Note:**

- *Avoid the use of this product at the high temperature and high humidity environment.*
- *Avoid self-disassembly of the products or it results in the voiding the product's Warranty.*
- *Turn off the speaker when the speaker is not in use.*
- *To know more about Terms and conditions for warranty policy, please visit*

<https://zebronics.com/pages/warranty-policy>

**Features:**

BT v5.3 / AUX / USB / mSD

Upto 16h\* Backup

Call Function

TWS Function

Dedicated Volume Knob

Dual Passive Radiator

Type-C Charging

16W RMS Output

RGB Modes

**Specifications:**

Output power (RMS) : 16W (8W + 8W)

BT version : 5.3

Driver Size : 52mm x 2

Speaker Impedance	: 3.6Ω
Frequency Response	: 100Hz-18kHz
S/N Ratio	: ≥70dB
Max. Supported USB/mSD Memory Size	: 32GB
Supported Audio Formats	: MP3
Charging Time	: 4h
Playback Time	: 16h*
Product Dimension (Dia x H)	: 35 x 6.2 x 7 cm
Net. Weight	: 667g

### **Package Contents**

Speaker	: 1 U
Input Cable	: 1 U
Charging Cable	: 1 U
QR Code Guide	: 1 U

*\* at 50% Volume (LED OFF)*

## Buttons and Ports



### 1 LED / Previous Track

- Short press the button to change the LED modes.
- Long Press the button to move to Previous Track

### 2 Mode / Next Track


- Short press the button to Switch between modes.
- Long Press the button to move to Next track.

### 3 Multifunction Knob

- Long Press the Knob to Power ON/OFF the Speaker.

- Turn the Knob Right to Increase the volume.
- Turn the Knob Left to Decrease the volume.
- Double press to enable TWS mode.

**Note :** The Volume Level will be indicated in the LED.



4 mSD card slot

6 Aux Input port

8 Charging Indication LED

5 USB Input port

7 Charging input port



## **Instructions for Use:**

### **Charging the Speaker**

1. Connect the Type-C to USB charging cable to the Type-C charging port of the speaker and insert the other end into a USB power source / mobile adapter.
2. Red LED glows constant indicating the speaker's battery is charging. The Red LED will turn off once it is fully charged.

### **BT Mode**

1. Once the speaker is Powered ON, it will enter into BT mode.
2. Switch ON BT in your phone or tablet and search for nearby BT devices.
3. Search for the BT name "**ZEB-VITA 102**" and tap on it to connect it.

### **USB/mSD Mode**

Insert the USB drive / mSD card into the respective ports of **ZEB-VITA 102** and the speaker would automatically start playing the MP3 files from the USB drive / mSD card.

### **TWS (True Wireless Stereo) function**

1. Keep both Speakers in BT discoverable Mode
2. Double press the "**MF Knob**" on either of the Speaker to enable TWS mode.
3. After a few seconds you will hear a

notification tone on both the speakers once both are successfully paired via TWS.

4. Now turn ON the phone's BT in the settings and search for **ZEB-VITA 102** and tap on it to pair with it.

5. If you would like to disconnect the two speaker from TWS, double press the **Mode** button.

***Note:** Buy another **ZEB-VITA 102** for true wireless stereo (TWS) setup.*

