



ZEBRONICS  
ALWAYS AHEAD

Portable BT Speaker  
**VITA BLAST**



User Manual

[www.zebronics.com](http://www.zebronics.com)

## **Dear Customer,**

Thank you for purchasing “**ZEB-VITA BLAST**” BT speaker. Please read this user manual carefully before operation & save it for future reference.

### **Note:**

- Avoid the usage of this product at the high temperature and high humidity environment.
- Avoid the self-disassembly of the products or it results in voiding the product's Warranty.
- Turn off the speaker when it is not in use.

To know more about Terms and conditions for warranty policy, please visit :

<https://zebronics.com/pages/warranty-policy>

### **Features :**

Wireless BT v5.1

Supports USB & mSD card

Built-in FM Radio

AUX Input

Call Function

Media / Volume control

Built-in Rechargeable battery

TWS Function

7 LED Modes

Dual passive radiators

## Specifications:



Output Power (RMS)	: 16W ( 8W + 8W)
BT Version	: v5.1
Driver Size	: 5.2cm x 2
Impedance	: 3Ω
Frequency Response	: 100Hz-18kHz
S/N Ratio	: ≥70dB
Max Supported USB/mSD memory size	: 32GB (USB)
Supported Audio formats	: MP3
Charging time	: 4.5h
Playback time	: 15h*
Product Dimension	: 40.6 x 8.5 x 7.2cm (W x D x H)
Net. Weight	: 722g

## Package Contents:

Speaker	: 1 U
Charging Cable	: 1 U
QR Code Guide	: 1 U

\* at 50% volume (LED off)

## Button Description:



1. Power / Mode Button & TWS mode
2. Play/Pause, Scan Button, LED Modes & LED on/off
3. Next / Volume+ Button
4. Prev. / Volume- Button
5. USB Port
6. Microphone
7. Type-C Charging Port
8. Micro SD Card Port
9. AUX Port

## **Button Functions:**

1. Long press the MODE button to power ON/OFF the speaker. Single Press the MODE button to change the input mode of the speaker.
2. Long press the “+” button to change the next track or channel when in BT/USB mode or FM mode respectively. Single press the button to Increase the speaker volume.
3. Long press the “-” button to go to the previous track/channel in BT/USB mode or FM mode respectively. Single press the “-” button to decrease the speaker volume.
4. Press the Play/Pause button to Play/Pause the track being played. Single press the same button to scan for FM channels in FM mode.
5. During calls, press the Play/Pause button to attend/end the call. Long press the Play/Pause button to reject an incoming call.
6. Double tap on MODE button to activate TWS Mode
7. Long press Play/Pause button to change LED light modes or on/off LED lights

## **Instructions for Use :**

### **Charging the Speaker :**

1. Connect the Type-C - USB charging cable to the Type-C charging port of the speaker and insert the other end into a USB Power source/mobile adapter.
2. Red LED glows constant indicating the speaker's battery is charging. The Red LED will turn off once it is fully charged.

### **Bluetooth :**

1. Once the speaker is Powered ON it will enter into BT mode.
2. Switch ON BT in your phone or tablet and search for nearby BT devices.
3. Search for the BT name **"ZEB- VITA BLAST"** and tap on it to connect it.

### **Micro SD / USB mode :**

Insert the Micro SD card / USB drive into the respective ports of ZEB- VITA BLAST and the speaker would automatically start playing the MP3 files from the Micro SD card/USB drive.

### **AUX-IN :**

Connect the speaker to any device using a 3.5mm to 3.5mm AUX cable. Once connected, the speaker automatically switches to AUX mode and the audio can be heard via the speaker.

## **TWS (True Wireless Stereo) Function :**

- Keep both speakers in BT discoverable mode.
- Double press the MODE button on either of the speakers for it to enable the TWS Mode.
- After a few seconds you will hear a notification tone on both the speakers once both are successfully paired via TWS.
- Now turn ON the phone's BT in the settings and search for "**ZEB- VITA BLAST**" and tap on it to pair with it.
- If you would like to disconnect the two speaker from TWS, double press Mode button.

*Note: Requires two speakers for TWS feature*

## **FM Radio :**

- Switch the speaker into FM mode. Single press the Play/Pause button to initiate the auto scan for available FM channels.
- Once scanning is complete, long press the + / - button to change the channels.

**ISO 9001:2015 Certified Company**

**[www.zebronics.com](http://www.zebronics.com)**

