



Portable BT Speaker

ZEB **ZEST 11R**



User Manual

www.zebronics.com

Thank you for purchasing the **“ZEB-ZEST 11R”** Portable BT Speaker. Please read this user manual carefully before operation & save it for future reference.

Note:

- Avoid the usage of this product at high-temperature and high-humidity environments.
- Avoid the self-disassembling of the product or it will result in voiding the Product's warranty.
- Turn off the speaker when the speaker is not in use.
- To know more about Terms and conditions for warranty policy, please visit

<https://zebronics.com/pages/warranty-policy>

Features:

- Wireless BT
- Supports USB & mSD Card
- AUX
- Built-in FM Radio
- Media / volume control
- Built-in Rechargeable Battery

Specifications:

Output Power (RMS)	: 10W
BT Version	: 5.1

Driver Size	: 10.16cm
Speaker Impedance	: 3Ω
Frequency Response	: 20Hz-20kHz
S/N Ratio	: ≥85dB
Max Supported USB/ MicroSD memory size	: 32GB
Supported Audio formats	: MP3
Charging time	: 3.5h
Playback time	: 6h*
Product Dimension (W x D x H)	
Handle Folded	: 12.8 x 9 x 20.5cm
Handle facing upwards	: 12.8 x 9 x 25cm
Net. Weight	: 670g

Package Content:

Speaker	: 1 U
Charging Cable	: 1 U
QR Code Guide	: 1 U

** at 50% volume(LED off)*

Button Description:



- 1. mSD Card Slot
- 2. AUX Port
- 3. Slider - Volume / Pause / Play / Next /Prev. / Mode
- 4. Charging Port (Type-C)
- 5. ON/OFF Switch
- 6. USB Port
- 7. Mic Input Port

Instructions for Use:

Button functions

1. Turn the speaker ON/OFF using the power switch.
2. Press & hold slider button to switch the modes.
3. Slide & hold it right or left to increase / decrease the volume.
4. Slide it right or left to change the NEXT/PREV tracks.
5. Single press slider button to Play/Pause the track being played.

Pairing with the BT Speaker:

1. Power ON the speaker and make sure it is in Bluetooth mode.
2. Switch ON BT on your phone or tablet and search for nearby BT devices.
3. Search for the BT name "**ZEB-ZEST 11R**" and tap to connect it.

Micro SD / USB Mode:

Connect the micro SD card / USB drive to the respective ports of the **ZEB-ZEST 11R** and the speaker will automatically start playing from the micro SD card / USB drive.

FM Radio:

- Once the speaker is turned ON, Please switch the speaker to FM mode using the slider button, Press & hold the slider button for 3 seconds.
- Single press the slider button to auto scan the available FM channels.
- Slide right or left slider to change the scanned FM channels
- Slide & hold right or left slider to adjust the volume

Note: Please use Power cable or AUX cable as antenna for better FM signal reception.

Charging the Speaker:

1. Connect the charging cable to the DC 5V Charging port of the speaker and insert the other end into a USB power source /adapter.
2. Red LED glows indicating that the battery is being charged.

