

Trolley DJ Speaker CCTANE100



User Manual

www.zebronics.com

Thank you for purchasing the "ZEB-OCTANE 100" Trolley DJ Speaker. Please read this user manual carefully abefore operation & save it for future reference.

Note:

- Avoid the use of this product at the hightemperature and high humidity environment.
- Avoid the self-disassembling of the product or it will result in voiding the Product's warranty.
- To know more about Terms and conditions for warranty policy, please visit

https://zebronics.com/pages/warranty-policy

Features:

- BT v5.0 | USB | mSD | AUX
- FM Radio
- 6.3mm Microphone Input
- Remote Control
- · Wireless Mic
- Up to 4.5h* Backup
- Karaoke Function
- RGB Lights
- LED Display
- Built-in Rechargeable Battery
- TWS Function
- MIC Recording
- 48W RMS Output

- Retractable Handle with Wheels
- Trolley Design
- Mic Volume & Echo Controls
- Volume, Bass & Treble Controls
- 30.48cm Full Range Drivers
- Tripod Mount

Specifications:

Output Power (RMS) : 48W

Driver Size

Full Range : 30.48 cm

Tweeter : 2.54 cm

Impedance

Full Range : 4Ω

Tweeter : 16Ω

Frequency Response : 65Hz-18kHz

S/N Ratio : ≥60dB

File Format Support

(USB/mSD) : MP3

Line Input : 3.5mm

Max Supported

USB/mSD Memory Size : 32GB

FM Frequency Range : 87.5 MHz - 108 MHz

Charging Time : 5.8h Playback Time : 4.5h*

BT Version : v5.0

BT Name : ZEB-OCTANE 100

Product Dimension : 32.7 x 26 x 51.5 cm

 $(W \times D \times H)$

Net. Weight : 4.9 kg


* at 50% volume(LED off)

Package Contents:

Speaker : 1 U Remote : 1 U Wireless Mic : 1 U Power Cord : 1 U Input Cable : 1 U Microphone Clamp : 1 U Warranty Card : 1 U QR Code Guide : 1 U

Product Description:


Control Panel Description:



- 1. Microphone Input Port
- 2. AUX In
- 3. Mic Echo Control Knob

- 4. Mic Volume Control Knob
- mSD Card Slot
- 6. LED Display
- 7. Charging Indication LED
- 8. Volume Control Knob
- 9. Bass Control Knob
- 10. Treble Control Knob
- 11. Power On/Off Switch
- 12. Next Track
- 14. Play/Pause & TWS
- 15. Previous Track
- 16. Mode Switch
- 17. USB Input Port
- 18. Charging Input Port

Remote Control:



- 1. Power On-Off
- 2. Bass Volume +
- 3. Treble Volume +
- 4. Bass Volume -
- 5. Treble Volume -
- 6. Mode Change Key (BT/AUX/USB/mSD/FM)
- 7. Volume +
- 8. Previous Track / FM Channel Key / Music

Rewind

- 9. Recording Key
- 10. Repeat Key
- 11. Mute / Unmute Key
- 12. Mic Volume +
- 13. Echo Volume +
- 14. Mic Volume -
- 15. Echo Volume -
- 16. Equalizer Preset
- 17. Next Track / FM Channel Key / Music

Forward

- 18. Play / Pause Key
- 19. Volume -
- 20. Play Recorded File
- 21. Mic Priority On-Off Key
- 22. Numberic Selection Key (0-9)

General Instructions

BT Connectivity:

- Switch the speaker to BT mode, scan for nearby BT devices in your source device (Mobile/ Tablet).
- Tap on "ZEB-OCTANE 100" to connect.

USB/mSD Mode:

 Insert the USB/mSD card to the speaker. The speaker will detect the USB Drive/mSD card and the audio Files from drive will be played automatically.

FM Radio:

 Switch the speaker to FM, In FM mode, Long press the Play/pause key to scan the available FM channels. Once the scanning is done, The speaker will start playing the first scanned channel.

AUX-IN:

- The speaker can be connected to an audio Device using a 3.5mm cable.
- Connect the one end of the cable to the speaker and Connect the other end of the cable to an audio source. The songs from the audio source can be heard through the speaker.

TWS Function:

- Turn on both "ZEB-OCTANE 100" Speakers in BT mode.
- Press and hold the Play/Pause Button for 3-5 Seconds in any one the speaker to initiate TWS pairing.
- After Few seconds both speakers will get connected Successfully.
- Now Search for nearby BT Devices in your Mobile phone or other source device and tap on BT name "ZEB-OCTANE 100" to Connect

Note: Requires two "ZEB-OCTANE 100" speakers for using TWS feature. To unlink them Press and hold the PLAY/PAUSE button for 3-5 seconds on either.

Recording Function:

- First Plug-in a USB/SD Flash card which will act as a storage device into the slot provided in the speaker.
- Press the REC button on the speaker or REC on the remote to Start /Stop the Recording.
- Press the REC PLAY button on the speaker or REC PLAY on the remote to play the Recorded file.

Charging the speaker:

- Connect the AC Cord to charge the speaker.
- RED LED will Flash while Charging.
- Once the speaker is Fully Charged, The RED LED Glows.

List of Service Centres Located across Tamil Nadu Region :

Location	Address & Contact Info
Chennai Mount Road	ZEB CARE, New No. 12, Old No. 144, Singanna Chetty Street, Nearby Hanuman Temple, Chintadripet, Chennai - 600 002, Tamil Nadu. Phone: 044 - 4214 9116, Mobile: 93450 86097, 93450 86097.
Vellore ASP	ZEB CARE, C/o, Smart Infotech, Near City Union Bank, 45, IDA Scudder Road, Vellore, Tamil Nadu - 632 004. Mobile : 99940 67767.
Trichy	ZEB CARE, No. D2, Second Floor KPRS Towers, No. 62/2, Tennur High Road, Tennur, Trichy - 620 017, Tamil Nadu. Phone : 0431 - 4051199.
Madurai	ZEB CARE, No. 30, First Floor, Krishnarayar Tank Street, Near Hanuman Temple, Madurai, Tamil Nadu - 625 001. Phone : 0452 - 4377340, Mobile : 99448 61446.
Salem	ZEB CARE, 1st Floor, SJ Tower, No. 19 A3, LIC Colony, Hotel Vasantham Road, Opp To New Bus Stand, Salem, Tamil Nadu - 636 004. Phone : 0427 - 4041904.
Coimbatore	ZEB CARE, 47/D, Valli Towers, First Floor, Radhakrishna Road, Opp To Karuna Suzuki, Tatabad, Coimbatore, Tamil Nadu - 641 012. Phone : 0422 - 3504727.
Tirunelveli ASP (Onsite)	ZEB CARE, Door No. 24/25, 2nd Floor, S.N. High Road, S.P.P. Building, Sripuram, Tirunelveli, Tamil Nadu - 627 001. Phone: 0462 - 4050014.
Tirunelveli	ZEB CARE, Door No. 24/25, 2nd Floor, S.N. High Road, S.P.P. Building, Sripuram, Tirunelveli, Tamil Nadu - 627 001. Phone: 0462 - 4050014.

ISO 9001:2015 Certified Company www.zebronics.com