





User Manual

www.zebronics.com

Dear Customer,

Thank you for purchasing **ZEB - SONO 200** Trolley DJ Speaker. Please read the user manual carefully before usage & save it for future reference

Note:

- Avoid the usage of this product at the high temperature and high humidity environment.
- Avoid the self-disassembly of the products or it results in voiding the product's Warranty.
- Turn off the speaker when the speaker is not in use.

-

To know more about Terms and conditions for warranty policy, please visit https://zebronics.com/pages/warranty-policy

Features:

- BT v5.0 | USB | mSD | FM | AUX | MIC IN | GUITAR IN
- Multicolor LED lights with On/Off switch
- Remote control
- · Wireless Mic
- Volume, Bass & Treble controls
- Mic Volume & Echo Controls
- TWS Function
- Built-in Rechargeable Battery
- Recording

- Karaoke
- Carry Handle with Wheels

Specification:

Output Power (RMS) : 200W

Driver Size : Full range -38.1cmX2

: Tweeter - 2.54cm x 1

Impedance : Full range - 4Ω

: Tweeter - 16Ω

Frequency response : 60Hz-18kHz

S/N Ratio : ≥65dB

File format support

(USB/mSD) : MP3, WMA, WAV

Line input : 3.5mm

Max supported

USB/mSD memory size: 32GB

FM frequency range : 87.5 MHz - 108 MHz

Charging time : 8h Playback time : 7h*

BT name : ZEB-SONO 200

BT version : v5.0

Product Dimension


(Dia x H) : 44 x 111 cm

Net.Weight : 16.6 kg

Package Contents


Trolley DJ Speaker: 1 U
Remote: 1 U
Wireless MIC: 2 U
QR Code Guide: 1 U
Input cable: 1 U
Power Cord: 1 U

Control Description



- 1. AC 220V/50Hz input
- 2. Volume knob
- 3. AUX IN
- 4. Bass knob
- 5. Power switch
- 6. Treble knob
- 7. Microphone Echo knob
- 8. Microphone Volume knob
- 9. Light switch
- 10. Guitar Volume knob
 - 11. Charging indicator
 - 12. External 12V input
- 13. mSD card port
- 14. USB port
- 15. Microphone input
- 16. Guitar input
- 17. Input mode & Long press On/Off the LED lights
- 18. Press the button to start record, again press to stop the recording.
- 19. Microphone priority button
- 20. Previous Track/FM channel key
- 21. Play/Pause/TWS Connection key
- 22. Next Track/FM channel key

Remote Control



- 1. Power On-Off
- 2. Bass volume +
- 3. Treble volume +
- 4. Bass volume -
- 5. Treble volume -
- 6. Mode change key (BT/AUX/USB/mSD/FM)
- 7. Volume +
- 8. Previous track / FM Channel key / Music Rewind
- 9. Recording key
- 10. Repeat key
- 11. Mute/Unmute key
- 12. Mic Volume +
- 13. Echo volume +
- 14. Mic Volume -
- 15. Echo volume -
- 16. Equalizer preset
- 17. Next track/FM channel key / Music Forward
- 18. Play/Pause key
- 19. Volume -
- 20. Play recorded file
- 21. Mic Priority On-Off key
- 22. Numeric selection key (0-9)

General Instructions

BT Mode

- Switch the speaker to BT mode, Scan for nearby BT devices.
- Tap on BT Name "ZEB-SONO 200" to connect.

USB/mSD Mode

• Insert the USB Drive/mSD Card to the speaker it will detect the USB Drive/mSD Card and the audio files from drive will be played automatically.

FM Radio

- Switch the speaker to FM, Now long Press the Play/Pause Key to scan the available FM channels.
- Once the scanning is done the speaker will start playing the first scanned channel.

AUX-IN

- The speaker can be connected to an audio device using a 3.5mm cable.
- Connect the one end of the cable to the speaker & connect the other end of the cable to an audio source.
- The songs from the audio source can be heard through the speaker.

TWS Connectivity:

- Turn on both "ZEB-SONO 200" speakers in BT mode
- Press and hold the Play/Pause button for 3-5 seconds in any one of the speaker to initiate TWS pairing.
- After few seconds both speakers will get connected successfully.
- Now search for nearby BT device in you mobile phone or other source device and tap on BT name ZEB-SONO 200 to connect.
- To exit TWS mode, press and hold the Play/Pause button for 3-5 seconds

Recording Function:

- To record mic input, first plug-in a USB/mSD card into the speaker, it will act as a storage device.
- Press the REC key on the remote to start/stop recording.
- Once the voice is recorded through the Mic, press the REC PLAY key to play the recorded file.

ISO 9001:2015 Certified Company www.zebronics.com