



Mini Soundbar
NEB
VITA BAR
301



User Manual

www.zebronics.com

Dear Customer,

Thank you for purchasing “ZEB-VITA BAR 301” Mini Soundbar. Please read this user manual carefully before operation & save it for future reference.

Note:

- *Avoid the use of this product at the high-temperature and high humidity environment.*
- *Avoid self-disassemble of product, or it will result in the failure of warranty.*
- *Please charge the product with power adaptor output rated voltage of DC 5V.*
- *To know more about Terms and conditions for warranty policy, please visit*

<https://zebronics.com/pages/warranty-policy>

Features

42W RMS Output

Upto 11h* Backup

Powerful Dual 57mm Drivers

BT v5.3 | USB | mSD | AUX

TWS Function

Dual Passive Radiators

9 RGB Modes

Call Function

LED Indicator

Compact Soundbar

Media / Volume Control

Type-C Charging

Built-in Rechargeable Battery

Specification


Output Power (RMS)	: 42W
Driver Size	: 5.7cm x 2
Impedance	: 4Ω x 2
Frequency Response	: 100Hz-18kHz
S/N Ratio	: ≥70dB
Separation	: ≥45dB
File Format Support	: MP3 (USB/mSD)
Line Input	: 3.5mm
Max. Supported Memory Size	: 32GB (USB/mSD)
BT Name	: ZEB-VITA BAR 301
BT Version	: v5.3
Charging Time	: 7h
Playback Time	: 11h*
Product Dimension	: 50 x 9 x 8 cm (W x D x H)
Net. Weight	: 1.2 kg

Package Contents

Speaker	: 1 U
Input Cable	: 1 U
Charging Cable	: 1 U
QR Code Guide	: 1 U

*@LED Off

Buttons & Ports Description:



1 Single Press to switch between available input modes.

Double Press to change the RGB LED Modes.

Long Press to power on/off.

2 Single-Press to Volume Down & Long-Press to Previous Track (BT/USB/mSD)

3 Play/Pause

♦ Single-Press to Play/Pause Track in BT/USB/mSD & Mute/Unmute in AUX.

♦ Long-Press to get into TWS Mode.

4 Single-Press to Volume Up & Long-Press to Next Track (BT/USB/mSD)

5 mSD Slot (Works only when mSD Card is Inserted)

6 USB Input Port (Works only when USB is Plugged In)

7 LED Indicator

8 Type-C Charging Port

9 AUX Input Port (Works only when AUX cable is Plugged In)

BT Connection:

Use the “**M**” button to switch the input to BT mode, You will hear a notification voice indicating BT mode and Blue LED flashes. Now turn on BT in your source device settings and tap on **ZEB-VITA BAR 301** and click pair. You will hear a notification voice indicating the pairing was successful.

USB Input:

Plug a pen drive into the USB port, and the speaker will switch automatically to USB mode and start playing the supported audio files.

mSD Input:

Insert mSD Card into the mSD Slot, and the speaker will switch automatically to mSD mode and start playing the supported audio files.

AUX Input:

Plug in the provided aux input cable to the speaker and plug the other end to any compatible audio output device.

***Note:** Media controls can be controlled only via audio source device*

Charging Instruction:

Use the provided Type C charging cable with a DC 5V/1A rated power adapter/charger.

ISO 9001:2015 Certified Company
www.zebronics.com

