




ZEB Tower Speaker
BT9500RUCF



User Manual

www.zebronics.com

Features:

1. With built—in amplifier design, the speaker reflect the purity of Sound and creates powerful sound effect.
2. Ideal for PC and audio sources such as CD, DVD, Bluray, TV, etc.
3. Magnetically shielded for use with PC monitor and TV without any interference.
4. Dedicated volume, treble, bass controls, plug and play microphone ports

Note:

1. Don't put the speakers in high temperature or humid environment, avoiding water and to prevent from electric shock.
2. Don' t open the speakers to avoid electric shock or other accidents.
3. In case of any liquid fallen into the speakers, cut off the power immediately and contact the nearby authorised service center.
4. When receiving high output signal from any audio sources(SD,USB ,AUX,FM) don' t turn the volume to maximum to avoid sound distortion.
5. For indoor use only.
6. Plug off the power plug in case of no utility for long period of time.

Utility Description:

1. Connect the one end of the right tower cable to the right output port on the back panel of the left tower. Also place the cable extended tower to the right side and the other to the left side while listening.
2. Connect one end of 3.5mm stereo audio plug to the audio output of PC or other audio sources.
3. Make sure all the cables above are connected correctly, then connect the power cord to AC power.
4. Switch on the power with the red led display showing(). then press power button either on the remote or left speaker front panel.
5. The SB mode in the mic represents the standby mode which works when the mic is to be stopped for few seconds or minutes without being switched off.


Package contents:

Tower speaker	: 2 units
Remote control	: 1 unit
Wireless Mic	: 2 units
Input cable	: 2 units
Antenna cable	: 1 unit

How to use the BT:

1. Select the audio input to BT status
2. Search BT device with name
"ZEB-BT9500RUCF"
3. Connect the BT
4. If your BT device below 2.0 version, input password "0000" when connecting.

Front Panel Description:



VOL- / CH-| Moves to the previous track for play if in USB or SD or BT mode moves to the previous channel if in the FM mode / decreases the volume level if pressed and held continuously.

AUTO / During FM playback press and hold for 2-3 sec to start auto scan for fm channels / Play or pause a current playing track.

VOL+ / CH+| Moves to the next track in USB or SD or BT mode moves to the next channel in the FM mode/Pressed continuously will increase the volume level.

EQ When USB/SD input, pressing the button will change to the various available equalizer modes.


INPUT Pressing it enables to switch between different audio sources FM, SD, USB, BT & AUX.

STANDBY Pressing it will put the speakers state to standby(or)during standby mode, Pressing it will enable the speaker to an active state.

SD/MMC CARD SD/MMC card slot


U DISK USB socket

Remote Control Description:



- Power** Power switch button(standby) switch On or off for waiting or On condition.
- USB** USB input
- SD** SD Input
- FM** FM Input
- AUX** AUX Input
- BT** BT Input
- EQ** Equalizer preset
- Play & pause** Play & pause
- Previous track** Previous track when USB/SD/BT Input;
- Rewind** Rewind
- Next track** Next track when USB/SD/BT Input
- Fast forward** Fast forward
- VOL-/+** Master Volume
- DISP** Lightness Adjust
- REPEAT** Repeat
- TUNE-/+** Previous/Next Channel Keep Pressing to search the channel
- CH-/+** Previous /Next Channel When FM Input
- AUTO** Keep Pressing For FM Channel
- SAVE** Save FM Channel
- RESET** When The Volume Is at The Maximum,Press "RESET" Button at The Status While Power On
- MUTE** Mute
- Press any key to choose the track**


Speakers Connectivity Diagram:



Note: Insert the plugs fully into the jacks. Loose connections may produce a humming sound or other noise interference.

Important: Connect the speakers and all other external device and finally connect the AC power cord.

Side Panel & Microphone Description:



VOLUME Volume control

TREBLE Treble control

BASS Bass control

ECHO-/+ Microphone echo control

MIC.VOL MIC volume.

Features:

2.0 Channel tower speaker

Wireless BT/USB/SD/AUX/FM

LED display

2 x 25.4cm Subwoofer

3 Way speaker

Remote control

Karaoke

Two wireless Mics

Dual microphone input jacks

Specification:

Output power (RMS) : 100W (50W + 50W)

Driver size

Subwoofer : 25.4 cm x 2

Mid : 10.16 cm x 2

Tweeter : 3.81 cm x 2

Impedance

Subwoofer : 4 Ω

Mid : 4 Ω

Tweeter : 4 Ω

Frequency response : 40Hz-20kHz

S/N Ratio : ≥ 75 dB

Separation : ≥ 45 dB

File format support : Mp3

(USB/SD)

Line input : 2ch RCA

Max. supported

USB/SD memory size : 32GB

FM frequency

scan range : 87 MHz - 108 MHz

BT name : ZEB-BT9500RUCF

BT version : 5.0 + EDR

Product dimension : 178 x 341 x 938 mm

(W x D x H)

Net. weight

(with amplifier) : 14.14 Kg

(w/o amplifier) : 11.14 Kg

ISO 9001:2015 Certified Company

www.zebronics.com

