ZEBRONICS

Wireless Keyboard & Mouse Combo

ZEB NITRO W100



User Manual

www.zebronoics.com

Thank you for purchasing **ZEB-NITRO W100** Wireless Keyboard & Mouse Combo. Please read this user manual carefully before usage & save it for future reference.

Note:

- Avoid self-disassembly of keyboard, kindly approach our service team with reference to the following link for service support:

https://zebronics.com/pages/warranty-policy

- Kindly charge the Keyboard and Mouse before usage. Use the Type-C cable provided in the package and a 5V DC adapter for charging.

Keyboard Features

- 65% Compact Layout
- Upto 3 BT connections
- 2.4GHz Wireless
- Laser Engraved Keycaps
- Integrated Multimedia keys
- 68 Keys
- Windows Lock Function
- 2 Step Retractable Stand
- Type-C Charging

Specifications

Model	: ZEB-MWK 4
Interface	: 2.4GHz + 3 BT
Total No.of Keys	: 68
Total No. of Mediakeys	: 7 (Integrated)
Keystrokes Life	: 5 Million cycles
Wireless Range	: 10 meter (without obstacles)
Product Dimension (W x D x H)	: 31.5 x 10.3 x 3.5cm
Net Weight	: 370 g

Mouse Features

- Upto 1 BT connections
- 2.4GHz Wireless
- High Precision
- Compact & Ergonomic Design
- Advanced Optical Sensor Technology
- 4 Level DPI switch
- Type C Charging
- LED Indicator
- Power Saving Mode

Specifications

Interface	: 2.4GHz + BT
Resolution	: 800|1200|2400|3400 DPI
No. of Button	: 6
Button Life	: 5 Million cycles
Wireless Range	: 10 meter (without obstacles)
Product Dimension	: 7 x 11 x 3.7 cm (W x D x H)
Net Weight	: 82 g

Package Contents

Keyboard	: 1 U
Mouse	: 1 U
Type-C + USB Dongle	: 1 U
Charging Cable	: 1 U
QR Code Guide	: 1 U

Instruction to use Keyboard:



1.Toggle the Switch to Turn On|Off the Keyboard.

2. Type-C Charging-Port : Use the Type-C cable Provided with the combo to charge the keyboard.

BT mode Connection:

- To enter BT mode, Turn On the Keyboard.
- Press and Hold Fn+BT1 / Fn+BT2 / Fn+BT3 Button, corresponding to BTl / BT2 / BT3 modes. You can notice the LED Blinks rapidly to indicate the BT Discover mode.



- Now open the BT menu in your PC / Laptop / Smartphone and scan for the device name ZEB-NITROK1/NITROK2/NITROK3 and pair it. Once connected, the LED blinking will stop.

RF Mode Connectivity:

- Remove the detachable top shell of the Mouse to access the USB/Type-C receiver stored inside the mouse.




- Press and hold Fn + 2.4GHz to enter 2.4GHz pairing mode. The green LED blinks to indicate 2.4GHz mode.



- Insert the USB/Type-C receiver into the desired device. The keyboard will automatically pair with the device.

Instruction to use Mouse :





Connectivity Procedure:

2.4GHz Wireless mode

Step 1: Plug the Type-C/USB Dongle into the PC
Step 2: On the rear side of the mouse, press the mode switch to enter into 2.4 GHz mode.
Step 3: TheGreenLED light emits for a few seconds and it turns off once it has been paired with the device.

BT mode

Step 1: On the rear side of the mouse, press the mode button to enter into BT mode. Now press and hold the mode button for 3 seconds to enter BT discovery.
Step 2: Open the BT menu on your BT device and search for BT name ZEB-NITROM1.
Step 3: The Blue LED light emits for a few seconds and it turns off once it has been paired with the device.

Charging instructions:

Kindly charge the Mouse before usage.The Green LED indicates the charging of Mouse. Once fully charged, the LED will goes OFF We suggest to use 5V DC adapter for charging.

Note:

The rechargeable battery provided with the mouse should not be replaced with a regular AA battery.

ISO 9001:2015 Certified Company
www.zebronics.com