

Wireless BT Keyboard K5001MW



User manual

www.zebronics.com

Thank you for purchasing ZEB-K5001MW Wireless BT Keyboard. Please read this user manual carefully before usage & save it for future reference.

Note:

- Avoid self-disassembly of keyboard, kindly approach our service team with reference to the following link for service support: https://zebronics.com/pages/service-centres
- Kindly charge the keyboard before usage. The RED LED indicates the charging of Keyboard. Once fully charged, the LED indication turns GREEN. We suggest to use 5V DC adapter for charging.

Features

Wireless BT
Slim & Full size minimalist design
UV Printed keycaps
Multiple OS Compatibility
Battery indicator
Built-In Rechargeable battery

Specifications

Interface : Wireless BT

Total No. of Keys : 99

Total No. of Hotkeys :13 (Integrated) Keystrokes life :5 Million cycles

Wireless range : 10 meter (without obstacles)

Product dimension $:36 \times 12.4 \times 1.5 \text{cm}$

 $(W \times D \times H)$

Net. Weight : 432g

Package contents

Keyboard:1 UType C Cable:1 UQR Code guide:1 U

Instruction to use: BT Mode Connectivity:

 Toggle the ON/OFF switch as shown in the below image.



 To enter BT discover mode, press and hold Fn + BT1 / Fn + BT2/ Fn + BT3 Button, corresponding to BT1 / BT2/ BT3 modes. You can notice the LED Blinks rapidly to indicate the BT Discover mode.



 Now open the BT menu in your PC / Laptop / Smartphone and scan for the device name ZEB-K5001MW and pair it. Once connected, the LED blinking will stop.

3 BT Connection and switching between the connections:

- The keyboard supports up to 3 BT connections, which can be switched as per usage. For instance, you can connect your smart phone, Laptop and other BT supported device on BT1/BT2/BT3 respectively.
- Once connected to the devices, you can press the FN+BT1 / FN+BT2 / FN+BT3 button (short press) to switch among the 3 BT connections.
- This helps you to keep the keyboard connected to all 3 devices in the same time and allows you to switch between them as per requirement.

All Key Functions:

Button	Combination Key Function	One Button Function
d× F1	F1	Mute
() F2	F2	Volume down
(d) F3	F3	Volume Up
4 4 F 4	F4	Previous track
DI F5	F5	Play / Pause
	F6	Next track
* F7	F7	Brightness -

*	F8	Brightness +
F9	F9	Select All
F10	F10	Сору
<u>D</u>	F11	Paste
<u>x</u> F12	F12	Cut
Delete	Fn Lock / Un-Lock	Delete
▲ Pg up	Pg UP	UP
▼ Pgdn	Pg Dn	Down
Home	Home	To the left end
End	End	To the right end
BT1	BT1 Pairing, press & hole Fn+BT1 at the same time to enter into pairing mode	
BT2	BT2 Pairing, press & hole Fn+BT2 at the same time to enter into pairing mode	
ВТЗ	BT3 Pairing, press & hole Fn+BT3 at the same time to enter into pairing mode	
	Screen capture key	

LED Indicators:

- O 1/BT1 ← Num Lock / BT1

○ ♠/BT3 ← Fn Lock / BT3

> ISO 9001:2015 Certified Company www.zebronics.com