

Wireless Gamepad **User Manual** 

Thank you for purchasing ZEB-MAX LINK Prowireless gaming pad. Please read the user manual before usage and save this user manual for future reference.

#### Note

- ZEB-MAX LINK PRO is a plug and play device. You can use this device without drivers
- Please unplug your Gamepad from your PC when it is not in use.
- Avoid Self Disassembly of the product or it results in voiding the Gamepad's Warranty.
- Please use our connector cable for charging your game pad.
- To know more about Terms and conditions for warranty policy, please visit

https://zebronics.com/pages/warranty-policy

#### **Features**

- Dual mode (BT + Wired)
- Support for PS4, PS3, Windows, iOS & Android\*\*
- Ergonomic design
- · Dual vibration motors

- RGB Light
- Hall Effect Jovsticks
- LED indicator
- · Twin front Analog triggers
- 6 Axis Gyro Sensor
- · Charging Dock Port & 3.5mm jack

# **Specifications**

Interface : BT + Wired

Compatibility: PS4, PS3, Windows,

iOS. Android\*\*

No. of Buttons : 19

No. of Analog sticks : 2

No. of Analog triggers : 2

No. of vibration motors: 2

Charging Time : 3.5h

UsageTime :10h\*

Product Dimension : 15.5 x 10 x 5 cm


 $(W \times D \times H)$ 

Net Weight : 235g

<sup>\*</sup>Without RGB lights, depending upon usage conditions

<sup>\*\*</sup>Depending upon Game and Device compatibility

# **Device Representation & Controls**



1-4 : Controls - □/x/0/△ Respectively

5 : Tigger R1

6 : Tigger R2

7 : Option

8 : Touch Pad/Touch pad button

9 : Share

10 : Tigger L2

11 : Tigger L1

12-15: Direction Pad - Up/Left/Down/Right

16 : Left Joystick

17 : Home/Mode

18 : Extension Port

19 : 3.5mm Jack

20 : Speaker

21 : Right Joystick

22-25: Macro Keys

26 : RGB Controller

## **PlayStation Parring**

To pair your controller for the first time or when using it with a different PS4 system, turn on the PS4 system and connect the controller to it using a USB cable. Then, press the PS (Home) button to establish the connection.

#### **PC Parring**

To pair your controller for the first time or when using it with a different PC, turn on Bluetooth on your PC and put the controller in Discover Mode by pressing and holding the Share and Home buttons. Open your PC's Bluetooth settings, search for the device named "Wireless Controller," and select it to connect and use the controller

# **Macro Function Set**

 Press and hold the ML+SL back button for 3 seconds until the channel indicator cycles through blue, red, and green. Release the button to enter programming mode. Press the ML key to save the programming. Click the ML key to activate the programming function, or press and hold the ML key to activate the loop function.

- Press and hold the MR+SR back button for 3 seconds until the channel indicator cycles through blue, red, and green. Release the button to enter programming mode. Press the MR key to save the programming. Click the MR key to activate the programming function, or press and hold the MR key to activate the loop function.
- The programming starts recording for 30 seconds and will automatically save the recording after that time. It can store up to 16 key functions. Simultaneously press and hold the SL+SR keys for 3 seconds until the channel indicator cycles through blue, red, and green. This will clear the programming function.

# Headphone Jack

To use the headphone jack\* on the controller, simply plug your headphones or headset into the jack. Ensure that the connection is secure. Once plugged in, the audio will be routed through your headphones, allowing you to listen privately while using the controller.

\*It should be connected to the PC via a wired connection, and the desired output must be selected.

#### **LED Modes**

Press the dedicated LED button to cycle through the built-in LED modes: Dynamic LED, Static LED, and LED Off.

## **Charging:**

Plug the Type-C cable into the controller. The light bar on the controller will blink slowly in orange to indicate charging has started. Once the controller is fully charged, the light bar will turn off.

#### **Charging Dock**

Align the charging connector on the station with the controller's extension port, then press the controller down until it clicks into place. The light bar on the controller will blink slowly in orange to indicate charging has started. Once the controller is fully charged, the light bar will turn off.

ISO 9001:2015 Certified Company

www.zebronics.com