





User Manual

www.zebronics.com

Features

High Effciency PCle Connector Single 45A 12V Rail Full Protection Built-in

Specifications

Input Voltage	: 230V
Input Current	: 5A
Fan Type	: Hydraulic bearing
Power Good Signal	: 100~500ms
Hold up Time	: ≤ 16ms
Protections	: OVP/OCP/SCP/OPP/UVP
Product Dimension	: 14 x 15 x 8.5 cm
	(W x D x H)
Net Weight	: 1.2kg

Package Content

Power Supply	:1U
Power Cord	:1U
Mounting Screws	:4U
QR Code Guide	:1U

Technical details:

AC input	230V AC 50Hz 5A				
DC Output (Max.)	+3.3V	+5V	+12V	-12V	+5Vsb
	20A	20A	45A	0.3A	2A

Installation:



Undo the thumb screws and remove the cabinet side panel.



Install the power supply inside the cabinet.



Fasten the power supply in the cabinet with provide screws.



Fix back the cabinet side panel and fasten the thumb screws.

Connection Description:

Motherboard 20+4 Pin Connector

$\Box\Box$	Pin	Description	Pin	Description
	1	+3.3V	13	+3.3V
	2	+3.3V	14	-12V
\Box	3	COM	15	СОМ
\Box	4	+5V	16	PS-ON
	5	COM	17	СОМ
	6	+5V	18	СОМ
\Box	7	COM	19	СОМ
	8	P.G.	20	NC
	9	+5V _{sb}	21	+5V
	10	+12V	22	+5V
	11	+12V	23	+5V
	12	+3.3V	24	СОМ

CPU 4 + 4 Pin



Pin	Description
1	СОМ
2	СОМ
3	+12V
4	+12V

PCI-e 6 + 2 Pin Connector



Pin	Description
1	+12V
2	+12V
3	+12V
4	СОМ

Pin	Description
5	СОМ
6	СОМ
7	СОМ
8	СОМ

S-ATA Connector



Peripheral 4-Pin Connector



Pin	Description
1	+12V
2	СОМ
З	СОМ
4	+5V

Troubleshooting

If your system does not turn on after installing the power supply, follow the troubleshotting guide as listed below:

- 1. Please make sure the main power is connected on correctly.
- 2. Please make sure the 24pin and 4/8pin connectors are connected correctly to the motherboard.
- If the power supply does not work properly, please contact our service center immediately.

Warranty:

Zebronics guarantees this product to be free of defects in material and workmanship, for more details on warrany duration please visit www.zebronics.com. This product is designed for desktop computer usage only. Using this product in any other application will void the warranty. Please ask for professional assistance for the installation. The warrany is valid only for the power supply unit, accessories are not included. Any abuse, alteration, misuse, negligence, incorrect volage supply, accidents and natural disarters will make the warranty invalid. Please visit our service center for issue with the product.



ISO 9001:2015 Certified Company www.zebronics.com