ZEBRONICS

Power bank

ZEB EnergiPod PB33



User Manual

www.zebronics.com

Thank you for purchasing the **ZEB-EnergiPod PB33** Power Bank. Please read this user manual carefully before operation and save it for future reference.

Note :

- Avoid the usage of this product at high-temperature and high-humidity environments.
- Avoid the self-disassembling of the product or it results in voiding the Product's warranty.
- Please charge the product with rated (DC 5V/2A via Type C or Micro USB port.

Caution :

There is a risk of explosion if the product is disposed of in the fire.

To know more about Terms and conditions for warranty policy, please visit
https://zebronics.com/pages/warranty-policy

Features :

Dual Output
LED Indicator
Mobile/Tablet Compatible
Type C & Micro USB Input
Over Charge Protection
Overload Protection
Short Circuit Protection


Specifications :

Battery Capacity	: 20000mAh
Input	: DC 5V/2A
Output 1	: DC 5V/2.4A
Output 2	: DC 5V/2.4A (total 2.4A max)
No.of Output Port	: 2
Charging Time	: 10 -11h
Product Dimensions	: 6.9 x 4 x 14 cm (W x D x H)
Net. Weight	: 398g

Package Contents :


Power Bank	: 1 U
Charging Cable	: 1 U
QR Code Guide	: 1 U

Port Description :




Note: Press and hold the power button for turn on / off the LED Flashlight

Charging Instructions :



Please charge the power Bank with Power adapter rated (DC 5V/2A) with Type C or Micro USB port.

Charging your Device with the Power Bank:



Connect your device with the Type C connector or Micro USB connector end of the cable and connect the other end of the cable to the power bank.