ZEBRONICS

Soundbar ZEB-ABABA2




User Manual

www.zebronics.com

Important Safety Instruction

Thank you for purchasing the **ZEB-ABABA 2** Soundbar. Please read this user manual carefully and keep for future reference.

Warning



Caution:

- To reduce the risk of electric shock, do not dismantle the product and do not expose the apparatus to rain or moisture. No user-serviceable parts inside.
- Refer servicing to qualified personnel only.



The lightning flash within an equilateral triangle is intended to alert you to the presence of uninsulated dangerous voltage within the product's enclosure that may be of sufficient magnitude to constitute an electric shock to a person or persons.



Important! This symbol alerts you to read and observe important warnings and instructions on the unit or in this manual.

Notice:



- To prevent possible hearing damage,do not listen at high volume levels for long time periods or a sudden high volume level.
- Never use the device unsupervised! Switch off the device whenever you are not using it, even if not using it only for a short while.
- The device is not intended to be operated by means of an external timer or separate remote control system.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

- Before operating this system, check the voltage of this system to see if it is identical to the voltage of your local power supply.
- The unit should not be impeded by covering the ventilation opening with items such as newspaper, table-cloths, curtains etc. Make sure that there are at least 20 cm of space above and at least 5 cm of space on each side of the unit.
- The unit must not be exposed to dripping or splashing liquid, no objects filled with liquids such as vases, should be placed on the device.
- To prevent fire or shock hazard, do not expose to direct heat, rain, moisture or dust.
- Do not position this unit near any water sources e.g. taps, bathtubs, washing machines or swimming pools. Ensure that you place the unit on a dry, stable surface.
- Do not place this soundbar close to a strong magnetic field.
- Do not place the soundbar on a amplifier or receiver.
- Do not place this soundbar in a damp area as the moisture will affect the life of electric components.
- Do not attempt to clean the soundbar with chemical solvents as this might damage the finish. Wipe with a clean, dry or slightly damp cloth.

- When removing the power plug from the wall outlet, always pull directly on the plug, never pull on the cord.
- Depending on the electromagnetic waves used by a television broadcast, if a TV is turned on near this unit while it is also on, lines might appear on the LED TV. Neither this unit nor the TV is malfunctioning. If you see such lines, keep this unit well away from the TV set.
- Clean only with dry cloth.
- Only use attachments / accessories specified by the manufacturer.


Important Notes

- Safety and operating instruction manual should be retained for future reference.
- open the casing of the unit; there are no user serviceable parts inside. Refer all servicing to qualified service personnel.


Power Source:

This soundbar is designed to operate in AC 220V-240V 50/60Hz.

Product Representation



1. Power ON/OFF
2. Previous/VOL-
3. Play/pause
4. Next/VOL+




1. AUX IN
2. TV (ARC)
3. USB
4. Optical
5. Coaxial
6. Subwoofer Out

Mount on the wall:

WARNING : If you don't feel confident to correctly and securely wall-mount the sound bar, Seek the assistance of an experienced person or professional.

Install the speaker on a vertical, fast, reinforced area of wall. For plaster walls, it is recommended to screw into wall studs for greater security. For optimum performance, allow at least 25mm/1"distance between the sound bar and the TV.




Follow below steps to mount the sound bar on the wall:

1. Open 2 holes in the wall referring to plastic bracket for wall mounting.
2. Fix the plastic anchor in the 2 holes of the wall mounting bracket.
3. Fix the wall mounting brackets to the wall by placing them over the holes and inserting the supplied screws into the plastic anchors. Tighten the screws properly using a screwdriver to ensure that the brackets are securely fixed and do not move or shake.

4. Align the soundbar with the installed brackets. Check the mounting holes on the soundbar and position them correctly with the wall mounting bracket.

5. Place the soundbar onto the brackets carefully and ensure it sits properly on both sides. After placing it, check that the soundbar is balanced, stable and securely supported by the brackets before use.



DISCLAIMER :
Soundbar Image representation is only for illustration purposes; actual product may vary.

Playing Audio via Bluetooth (BT)
1. Turn on the soundbar. Short-press the Mode button until the LED display shows "BT".
2. Enable Bluetooth on your phone or other device and select "ZEB-Ababa 2" from the list.
3. Once paired, you will hear a tone and the LED will remain on.
4. Use the soundbar's remote control for BT playback functions (Play/Pause/Next/Prev).

Playing Audio via USB
1. Insert a USB flash drive into the USB port.
2. The soundbar will automatically switch to USB mode and begin playback.

Note : *This mode cannot be selected unless a USB drive is inserted.*

Audio Input (AUX) Connection
1. Connect the soundbar to your PC, tablet, smart phone, or TV using the included AUX cable.
2. Playback can only be controlled from the connected device in this mode.

TV Connection via TV (ARC)
1. Ensure your TV supports TV ARC.
2. Connect one end of a High-Speed HDMI cable to the TV's ARC port and the other to the soundbar's TV (ARC) port.
3. Select TV ARC mode on the soundbar.
4. Control volume via your TV remote.

Playing Audio via Bluetooth (BT)
1. Turn on the soundbar. Short-press the Mode button until the LED display shows "BT".
2. Enable Bluetooth on your phone or other device and select "ZEB-Ababa 2" from the list.
3. Once paired, you will hear a tone and the LED will remain on.
4. Use the soundbar's remote control for BT playback functions (Play/Pause/Next/Prev).

Playing Audio via USB
1. Insert a USB flash drive into the USB port.
2. The soundbar will automatically switch to USB mode and begin playback.

Note : *This mode cannot be selected unless a USB drive is inserted.*


Audio Input (AUX) Connection
1. Connect the soundbar to your PC, tablet, smart phone, or TV using the included AUX cable.
2. Playback can only be controlled from the connected device in this mode.

TV Connection via TV (ARC)
1. Ensure your TV supports TV ARC.
2. Connect one end of a High-Speed HDMI cable to the TV's ARC port and the other to the soundbar's TV (ARC) port.
3. Select TV ARC mode on the soundbar.
4. Control volume via your TV remote.

Optical Mode:

Use this operating mode to play music from the optical digital input for example from a TV on your soundbar. The TV must have an optical digital output. Use the optical cable to make the connection. Proceed as follows:

1. Connect the optical cable to the optical digital output of your TV.
2. Then connect the optical cable to the optical digital input of your soundbar.
3. Press the "MODE" button on the remote control to select optical mode.
4. You can use the volume buttons to adjust the volume to your requirements.
5. In this mode, playback can only be controlled on your connected device.



Coaxial Mode:
1. Use this operating mode to play music from the Coaxial digital input for example from a TV Coaxial OUT to the soundbar Coaxial IN. (TV must have Coaxial output)
2. Connect the Coaxial cable between the soundbar and TV.
3. Switch to Coaxial input mode and start playing content on TV.
4. You can use the volume buttons to adjust the volume as per your requirements.

Features:

- Sound Bar with Quad Drivers
- Slim Design with Touch control
- 13.33 cm Subwoofer
- Multi Connectivity (BT v5.3 | TV (ARC) | Coaxial IN | Optical | USB | AUX)
- Volume & Media Control
- Glossy Finish
- LED Display
- Remote Control
- Wall Mountable

Specifications:

Model	: ZEB-ABABA 2
Driver Size	
Subwoofer	: 13.33cm x 1
Soundbar	: ((Full range - 4 x 7 cm) x 2) + ((Tweeter 2.8cm) x 2)
Impedance	
Subwoofer	: 4Ω
Soundbar	: (Full range 6Ω + Tweeter 6Ω)
Frequency response	: 200Hz-20kHz
S/N Ratio	: ≥78dB
Separation	: ≥38dB
File format support (USB)	: MP3
Line Input	: 3.5mm, Coaxial IN, Optical & TV (ARC)
Max supported memory size (USB)	: 32GB
BT name	: ZEB-Ababa 2
BT version	: v5.3
Product Dimensions (W x D x H)	
Subwoofer	: 17 x 32 x 30 cm
Sound Bar	: 100 x 8.2 x 5.5 cm

Net.Weight

Subwoofer	: 2.9 kg
Sound Bar	: 1.4 kg
Total	: 4.3 kg

Package Contents:

Sound Bar	: 1 U
Subwoofer	: 1 U
Remote Control	: 1 U
Input Cable	: 1 U
Wall Mount Kit	: 1 U
Powercord	: 1 U
QR Code Guide	: 1 U

ISO 9001:2015 Certified Company
www.zebronics.com