



Presentation Pointer

ZEB **PP250**



User Manual

www.zebronics.com

Dear Customer,

Thank you for purchasing the **"ZEB-PP250"** Presentation Pointer. Please read this user manual carefully before operation and save it for further reference.

Safety Measures:

- *To avoid possible eye damage, never point the device at people especially their faces, or look directly into the device's laser beam.*
- *Avoid pointing the device's laser beam at a mirror or other highly reflective surface.*
- *Keep the device away from children.*
- *Never view the device's laser beam using telescopic devices, such as a microscope or binoculars.*
- *Any attempt to disassemble, adjust or repair the device may result in exposure to laser light or other safety hazards.*

To know more about Terms and conditions for warranty policy, please visit

<https://zebronics.com/pages/warranty-policy>

Features:

- 2.4GHz Wireless
- 100+ Meter LASER range
- Multi OS Compatible
- Upto 50 meter Wireless Range
- Page Flip Buttons

- USB Receiver
- Plug & Play
- Bright Red LASER
- Multiple Software Support
- LED Indicator
- Anti-Slip Grip

Specifications:

Connectivity	: USB Receiver (2.4GHz)
LASER Emitter Class	: Class 3R
LASER Color	: Red
No. of Buttons	: 5 nos + 1 On/Off Switch
Battery Slot	: AAA x 2
Product Dimension	: 3.6 x 2.8 x 11.5 cm (W x D x H)
Dongle Dimension	: 1.7 x 0.8 x 4.6 cm (W x D x H)
Net Weight	: 35g

Package Contents :

Laser Pointer	: 1 U
USB Receiver	: 1 U
QR Code Guide	: 1 U

Product Description:



1. LED Indicator
2. Laser Button
3. Page Up Button
4. Page Down Button
5. Full Screen Button
6. Black Screen Button
7. USB Receiver
8. Power On/Off

Usage Instructions:

- Slide the Power Switch to turn the pointer On/Off.
- Pull out the USB receiver and plug it into a compatible USB port.
- The device will automatically recognize the pointer.
- Open your PPT file using compatible presentation software.
- Press the Laser Button to activate the laser pointer during presentations.
- Use the Page Up and Page Down buttons to navigate between slides.
- Press the Full Screen Button to enter slideshow full-screen mode.
- Press the Screen Black Button to temporarily black out the presentation screen.
- After usage remember to keep the USB Receiver inside the pointer and slide the power switch off.

Note: *The button functions may vary upon the software compatibility*



CAUTION LASER RADIATION



DO NOT STARE INTO BEAM

Wavelength : 630 - 650nm

AAA x 2 Batteries*

Max Output : <5mW

Class 3R LASER Product

*Battery Not Included

ISO 9001:2015 Certified Company
www.zebronics.com