



Gamer's Dream



# Premium Microphone ZEB **LUCID** PRO

## User Manual

[www.zebronics.com](http://www.zebronics.com)

[www.zebclan.com](http://www.zebclan.com)

Dear Customer,

Thank you for purchasing **ZEB-LUCID PRO** Condenser Microphone (Plug & Play). Please read the user manual carefully before usage & save it for future reference.

### Note:

- Avoid the self-disassembly of the product as it results in the failure of Warranty.

### Features:

Plug and Play

Cardioid polar pattern

Compatible with Computers & Laptops

Suspended Scissor Arm

Pop filter with flexible neck

Crisp and clear audio

Desktop mount

Metal body

### Specifications:

Type : Condenser Microphone

Polar Pattern : Cardioid

Power Input : 5V DC

Frequency

Response : 100Hz – 18000Hz

Sensitivity :  $-42 \pm 3$ dB

SNR :  $\geq 70$ dB

OS Compatibility : Windows, Linux, Mac

Cable Length	: 2m
Microphone Dimension	: 50 x 160mm
Connector Type	: USB
Net Weight	: 920g

### Package Contents:

Microphone	: 1 U
USB Cable	: 1 U
Scissor Arm Stand	: 1 U
Shock Proof Mount	: 1 U
Table Mounting Clamp	: 1 U
POP Filter	: 1 U
POP Filter Holder	: 1 U
Foam Mic windscreen	: 1 U
QR Code Guide	: 1 U

### Product Representation:



## ZEB-LUCID PRO Installation:



1. Tighten the table mounting clamp on the table properly.
2. Place the Scissor arm into the table mount and make sure to screw it tight.
3. Fix the shock mount thread carefully into scissor arm stand & screw it tight.
4. Place the microphone inside the shock mount.
5. Fix the POP Filter as shown in the image.



### Usage and Settings:

1. Connect the USB to the PC directly, with the cable provided.
2. Once connected to your PC USB port, the mic will get detected as the default device, automatically. You can also set the preference manually, by entering system Sound settings.
3. If necessary you can adjust the mic sensitivity settings inside your Computer's settings / Sound menu.
4. While being used in applications / softwares, you can once check the application / software device priority and assign ZEB – LUCID PRO mic as the priority.

Kindly mail us on **support@zebronics.com** for technical assistance.



ISO 9001:2015 Certified Company  
[www.zebronics.com](http://www.zebronics.com)  
[www.zebclan.com](http://www.zebclan.com)