ZEBRONICS

## Tower Speaker
ZEB BT505RUCF

User Manual

Dear Customer,

Thank you for purchasing **"ZEB-BT505RUCF" Tower Speaker.** Please read the user manual carefully before usage & save it for future reference.

Note:

- Avoid the usage of this speaker at high temperature and in high humid environment.
- Avoid self-disassembly of the product as it results in the failure of Warranty.

Features:

Wireless BT/USB/FM/AUX
LED display
13.33cm Subwoofer
Wireless Mic
Remote control
FM Radio

Specification:

Output power (RMS)	: 50W
Driver size	
Subwoofer	: 13.33cm
Full range	: 7.62cm x 2
Impedance	
Subwoofer	: 8Ω
Full range	: 4Ω
Frequency response	: 40Hz- 20kHz
S/N Ratio	: ≥75dB

Line input	: 2ch RCA
Max. supported USB memory size	: 32GB
FM frequency scan range	: 87.5MHz-108MHz
BT Name	: Zebronics
BT version	: 5.1
Product dimension	: 16x26x62cm (W x D x H)
Net. weight	: 5.3kg

Package Content:

Speaker	: 1U,
Remote	: 1U,
Mic Holder	: 1U
Wireless Mic	: 1U,
Wall Mounting Kit	: 1U,
Input Cable	: 1U,
QR Code Guide	: 1U.

Control panel:

LED Display

Volume control Knob

Play/Pause Long Press to Scan (FM channel)

Next Track / FM Channel

Previous Track / FM Channel

Mode (BT/ AUX/USB/FM)

USB

Remote:

Power ON/OFF — Mute/Unmute

Numeric pad

Mode (BT/USB/ FM/AUX) — Equalizer

Repeat — Scan (FM Mode)

Increase volume

Previous Track — Next Track

Decrease volume

Play/Pause
Next channel
(FM Mode)

ZEBRONICS

General Instructions

BT Mode:

Switch the source to BT mode, scan for nearby BT devices on your device. Tap on "Zebronics" to connect.

USB Mode:

Insert the USB drive to the slot provided on the sub woofer. It will detect the USB and the audio files from drive will be played automatically.

FM radio:

Switch the source to FM mode. Press the SCAN button in the remote to scan for the available FM channels.

On the Subwoofer Long press Play/Pause button to scan for the available FM channels .Once the scanning is done, the first scanned channel will begin to play. The next/previous button in the subwoofer or Play/pause button in remote can be used to change the FM channels.

AUX-IN:

The device can be connected to an audio device using an RCA to 3.5mm cable. Connect the one end of the cable to the speaker and the other end to an audio source. The songs from the audio source can be heard through the speaker.