



User Manual

www.zebronics.com

Thank You for purchasing **ZEB-ESCAPE 10** wireless neckband earphone. Please read this user manual carefully before operation & save it for future reference.

Note:

- Please full charge the product with a power adapter output rated DC 5V before first time usage.
- Avoid the self-disassembly the product or it results in the voiding the product's warranty.

To know more about Terms and conditions for warranty policy, please visit

https://zebronics.com/pages/warranty-policy

Caution:

Listening at high volume can cause hearing impairment. Please limit your usage time at high volume.

Features

Wireless BT earphone with Neckband Volume/Media Control Magnetic Earpiece Call Function Voice Assistant support Built-In Rechargeable Battery

Specifications

BT Version : v5.3

BT Profile : HSP / HFP / A2DP /

AVRCP

Drive size : 10mm

Speaker impedance: 16Ω

Playback time : 20 h* Charging time : 1.5 h


Talk time : 20 h*
Standby time : 200 h

Net. weight : 27g

Package contents

Neckband :1 U Charging Cable :1 U OR Code Guide :1 U

Product Representation



1. + Button

Short press: Volume up **Long press**: Next track

2. MFB Button

Single press: Play / Pause

Press and hold for 3 seconds: Voice assistant

Long press and hold: Power On/ Power off

When calling (MFB Button on Middle):-

Single press: Accept / End the

ongoing call

Double press: Direct incoming Call rejection

Double press: Redial

3. - Button

Short press: Volume down **Long press**: Previous track

Usage Instruction

Bluetooth Pairing Instructions:

STEP 1 - Press and hold the MFB button to power ON the earphones.

STEP 2 - Switch ON the BT in your mobile phone & search for the BT name "ZEB-ESCAPE 10"

STEP 3 – Once the BT name is visible in your mobile phone, tap to connect it.

Activating Smart Phone's Voice Assistant

When the neckband is connected to a mobile phone, Press and hold the MFB Button for 3 seconds to activate voice assistant.

Note: Smart phone should have an active internet connection to use the voice assistant function.

Call Function:

- Single press the MFB button to attend / end the Call and Double press to reject the incoming call.
- Double press the MFB button for Redialing.

Led Indication

1	Charging the Neckband	Red light glows-(charging) Blue Light Glows - Fully charged
2	BT pairing	Red and blue blinks – BT discovery mode Blue blinking - BT paired successfully
3	Power on / off	Blue Blinking – while power On Red Blinking – while power Off

Charging Instruction

Connect the Type-C charging cable to the charging port of the Neckband & connect the other end to the DC 5V adapter.

ISO 9001:2015 Certified Company www.zebronics.com