



ZEBRONICS
ALWAYS AHEAD

4 . 1 S p e a k e r
ZEB SPARK



User Manual

www.zebronics.com

Dear Customer,

Thank you for purchasing ZEB-SPARK 4.1 Speaker. Please read the user manual carefully before usage & save it for future reference.

Note:

- Avoid the usage of this speaker at the high temperature and high humidity environment.
- Avoid the self-disassembly of the product as it results in the failure of Warranty.

Features

4.1 Channel speaker

Wireless BT/USB/AUX/FM

LED display

Volume, Bass & Treble adjustment

Remote control

Wall mountable

Specification

Output Power (RMS)

Subwoofer : 50 Watts

Satellite : 10 Watts x 4

Total : 90 Watts

Driver size

Subwoofer : 13.3cm

Satellite : 7.62cm x 4

Impedance

Subwoofer : 4Ω


Satellite : 8Ω

Frequency response	: 20Hz - 20kHz
S/N Ratio	: ≥ 72 dB
Separation	: ≥ 45 dB
File format support (USB):	MP3
Line input	: 2ch RCA
Max. supported USB memory size	: 64GB
FM frequency range	: 87.5 MHz - 108 MHz
BT name	: ZEB-SPARK
BT version	: 5.0
Product dimension (W x D x H)	
Subwoofer	: 180 x 325 x 265 mm
Satellite	: 105 x 85 x 180 mm
Net. weight	
Subwoofer	: 4.51kg
Satellites	: 314g x 4
Total	: 5.7kg

Package contents


Subwoofer	: 1 U
Satellite	: 4 U
Remote control	: 1 U
Input cable	: 1 U
QR Code guide	: 1 U

Description of the Subwoofer front control panel:




1. LED Display, 2. USB Port, 3. Volume control
4. Play/Pause/Scan, Mode, 6. Previous
7. Treble control, 8. Next, 9. Bass control

Description of the Subwoofer back control panel:



Remote Control:



General instruction

BT Mode:

Switch the speaker to BT mode, Scan for nearby BT devices in your device. Tap on ZEB-SPARK to connect.

USB Mode:

Insert the USB drive to the speaker. The speaker will detect the USB and the audio files from drive will be played automatically.

FM radio:

Switch the speaker to FM mode. In FM mode, long press the play button to scan for the available FM channels. Once the scanning is done, the first scanned channels will begin to play. The next button or previous button can be used to change the FM channels

AUX-IN:

The speaker can be connected to an audio device using an RCA to 3.5mm cable. Connect the one end of the cable to the speaker and the other end to an audio source. The songs from the audio source can be heard through the speaker

ISO 9001:2015 Certified Company
www.zebronics.com

