



Gamer's Dream

**WIRELESS PREMIUM  
MECHANICAL KEYBOARD**

**ZEB MAX**  
*Ninja 200*



**User Manual**

[www.zebronics.com](http://www.zebronics.com)

Thank you for purchasing **ZEB-MAX NINJA 200** Wireless premium mechanical keyboard. Please read this user manual carefully before usage & save it for future reference.

### **Note**

- Avoid self-disassembly of keyboard, kindly approach our service team with reference to the following link for service support:

<https://zebronics.com/pages/service-centres>

- Kindly charge the keyboard before usage. The RED LED indicates the charging of Keyboard. Once fully charged, the LED indication turns GREEN. We suggest to use 5VDC adapter for charging.
- Use the Type C cable provided inside the package for wired mode usage.

### **Features**

75% Compact design

Multi Mode (BT/2.4GHz RF/Wired)

N Key rollover

Comfortable silent tactile feeling

18 backlit LED Modes

4 Levels of Brightness + 1 LED Off

4 Levels LED speed modes

Windows key Disable / Enable function

Heavy Duty  
Detachable type C cable  
Upto 3 BT connections  
Bottom Rubber Grip  
2.4GHz RF mode  
USB nano receiver  
Detachable Type C to USB A cable  
Hot Swappable keys  
Windows / Mac / IOS / Android OS Compatible  
Battery Level Indicator  
Red Switch

### Specification

Interface	: Multi Mode (BT/2.4GHz RF/Wired)
Keyboard Type	: Mechanical
Total No. of Keys	: 84 nos
Keystroke	
Key Pressure	: 50±10gf
Key Travel	: 4.0±0.2mm
Key Life Span	: 50,000,000 times
Polling Rate	
2.4Ghz & Wired	: 1000Hz
BT	: 125Hz
Cable Length	: 1.8m
Power Consumption	: DC 5V, <300mA (max)
Product Dimension (W x D x H)	: 31.5 x 12.5 x 4.0 cm
Net. Weight	: 814g

## Package Content

Mechanical Keyboard	: 1 U
Type C to USB A cable	: 1 U
Key Removal Tool	: 1 U
Nano Receiver	: 1 U
QR Code Guide	: 1 U
Spare Z Keycap	: 1 U
Switch Removal Tool	: 1 U

## Instructions for use

### Wired mode connection with Type C cable

- Connect the USB A to Type-C cable from the PC/Laptop to the keyboard.
- Set the Keyboard to wired mode by pressing Fn + wired mode key. It can be identified with the inscription 'Wired' on the key.



- Once connected, the keyboard will automatically start working in wired mode.

### RF 2.4GHz mode

- RF 2.4GHz mode can be toggled by pressing Fn + '2.4G' key on the keyboard.



- Now connect the Nano Receiver to the PC/Laptop's USB port.
- Once connected, the keyboard will start working in 2.4GHz RF mode (plug and play)

### BT mode connectivity

- To enter BT discover mode, press and hold Fn + BT1 / Fn + BT2 / Fn + BT3 button, corresponding to BT1 / BT2 / BT3 modes. You can notice the LED blinks rapidly to indicate the BT discover mode.



- Now open the BT menu in your smart phone / Laptop / smartphone and scan for the name **ZEBNINJA200** and pair it. Once connected, the LED blinking will stop.

### **3 BT connection and switching between the connections**

- The keyboard supports up to 3 BT connections, which can be switched as per usage. For instance, you can connect your smart phone, Laptop and other BT supported device on BT1 / BT2 / BT3 respectively.
- Once connected to the devices, you can press the FN+BT1 / FN+BT2 / FN+BT3 button (short press) to switch among the 3 BT connections.
- This helps you to keep the keyboard connected to all 3 devices in the same time and allows you to switch between them as per requirement.

### **Other key functions**

- To turn OFF the keyboard, press & hold FN+5. (Note: It will not turn OFF while in wired mode)
- To turn ON the keyboard, short press FN+BT1 / FN+BT2 / FN+BT3 / FN+2.4G / FN+Wired.

- To switch between windows & mac mode, press FN+A for Windows mode & press FN+S for Mac mode.
- To reset the entire keyboard to default mode press & hold FN+Esc.

## **LED Functions**

- Press FN+~ to toggle between different LED modes.
- To change the intensity of the LED, press FN+Up arrow to increase the intensity & to decrease the intensity press FN+Down arrow.
- To Increase the speed of the LED, press FN+= to increase the speed & to decrease the speed press FN+-
- To change the direction of the LED light, press FN+Left arrow.
- To access the different color combinations, press FN+Right arrow.
- To turn OFF the LED, press FN+K
- To enable / disable the windows key, press FN+Windows key

## **Battery Indicator**

- Battery percentage can be monitored & it can be viewed from 1 to 0 keys (Eg: 1st key represents 10%, 9th key represents 90% & 0th key represents 100%).
- It can be accessed by pressing FN+Space bar.



ISO 9001:2015 Certified Company  
[www.zebronics.com](http://www.zebronics.com)